





8 mm  
21–25 N·m  
(2.1–2.5 kg·m, 15–18 ft·lb)




6 mm  
10–14 N·m  
(1.0–1.4 kg·m, 7–10 ft·lb)



6 mm  
10–14 N·m  
(1.0–1.4 kg·m, 7–10 ft·lb)

9 mm  
30–34 N·m  
(3.0–3.4 kg·m, 22–25 ft·lb)





SERVICE INFORMATION	11-1
CRANKCASE DISASSEMBLY	11-2
CRANKCASE ASSEMBLY	11-3

## SERVICE INFORMATION

### GENERAL

- To service the pistons, crankshaft, connecting rods and transmission, the crankcase halves must be separated.
- The following parts must be removed before disassembling the crankcase.
  - Oil pan Refer to section 2
  - Oil pump Refer to section 2
  - Water pump Refer to section 6
  - Clutch/starter clutch Refer to section 7
  - Gearshift linkage Refer to section 8
  - Alternator Refer to section 9
  - Cylinder heads Refer to section 10
  - Starter motor Refer to section 19

### TORQUE VALUES

9 mm bolt:	30–34 N·m (3.0–3.4 kg·m, 22–25 ft·lb)
8 mm bolt:	21–25 N·m (2.1–2.5 kg·m, 15–18 ft·lb)
6 mm bolt:	10–14 N·m (1.0–1.4 kg·m, 7–10 ft·lb)

### TOOLS


<b>Special</b>	
Driver	07949–3710000
<b>Common</b>	
Attachment, 52 x 55 mm	07746–0010400

## CRANKCASE DISASSEMBLY


Refer to Service Information (page 11-1) for removal of necessary parts before disassembling crankcase.

Remove the countershaft bearing cover.

Remove the neutral switch cover and the switch (page 20-3).



Remove the mainshaft bearing holder by removing the screw and bolts.



Remove the upper crankcase bolts.





Turn the engine over and remove the lower crankcase bolts.


**NOTE:**

Remove the bolts in two or more steps and in a crisscross pattern to prevent distorting the crankcase.


Separate the crankcase.

Remove the following parts:

- Piston and connecting rods (Section 12).
- Crankshaft (Section 12).
- Shift fork and shift drum (Section 13).
- Transmission (Section 13).




Drive the countershaft bearing out of the case.



COUNTERSHAFT BEARING

## CRANKCASE ASSEMBLY

Drive the countershaft bearing into the crankcase.







## CRANKCASE

Install the following parts:

- Shift fork and shift drum (Section 13).
- Transmission (Section 13).
- Crankshaft (Section 12).
- Piston and connecting rods (Section 12).



Apply molybdenum disulfide grease to the shift fork grooves of the M2/3, C4 and C5 gears.






Clean the crankcase mating surfaces.  
Apply liquid sealant to the mating surface of the lower and upper crankcase.


**CAUTION**

*Do not apply sealant to the area near the main bearings.*

DO NOT COAT THIS AREA.



Install the dowel pin into the lower crankcase.




DOWEL PIN

Assemble the crankcase halves, aligning the shift forks with the gears.  
Tighten the bolts to the specified torque values in the sequence shown.

**TORQUE VALUES:**

- 9 mm bolt: 30–34 N·m  
(3.0–3.4 kg·m, 22–25 ft·lb)
- 8 mm bolt: 21–25 N·m  
(2.1–2.5 kg·m, 14–18 ft·lb)
- 6 mm bolt: 10–14 N·m  
(1.0–1.4 kg·m, 7–10 ft·lb)

Tighten the bolts in a crisscross pattern and in 2–3 steps.




## CRANKCASE

Tighten the upper crankcase bolts to the specified torque in a crisscross pattern and in 2–3 steps.

**TORQUE:** 8 mm: 21–25 N·m  
 (2.1–2.5 kg·m, 15–18 ft·lb)  
 6 mm: 10–14 N·m  
 (1.0–1.4 kg·m, 7–10 ft·lb)

### NOTE

Make sure that the plain washers are under the 8 mm bolt heads and the battery ground cable is under the 6 mm bolt head as shown.




Install the mainshaft bearing holder and tighten the screw and bolts.



Install the neutral switch and cover (page 20-3).

Install the dowel pins and a new gasket on the countershaft bearing cover mounting surface.






Apply grease to the countershaft oil seal lip in the countershaft bearing cover, then install it being careful not to damage the oil seal lip.







SERVICE INFORMATION	12-1	BEARING INSPECTION	12-8
TROUBLESHOOTING	12-2	BEARING SELECTION	12-10
CONNECTING ROD REMOVAL	12-3	CRANKSHAFT INSTALLATION	12-12
PISTON REMOVAL	12-4	PISTON AND ROD INSTALLATION	12-13
CRANKSHAFT REMOVAL	12-7		

## SERVICE INFORMATION

### GENERAL

- All bearing inserts are select fit and are identified by color code. Select replacement bearings from the code tables. After installing new bearings, recheck them with plastigauge to verify clearance.
- Apply molybdenum disulfide grease to the main journals and crankpins during assembly.
- Before removing the piston and connecting rod assemblies, clean the top of the cylinder of any carbon deposits.
- For servicing the piston, connecting rod and crankshaft, the crankcase assembly must be separated (Section 11).

### SPECIFICATIONS

ITEM		STANDARD		SERVICE LIMIT	
Crankshaft	Connecting rod big end side clearance		0.10–0.30 mm (0.004–0.012 in)	0.40 mm (0.016 in)	
	Runout		—	0.03 mm (0.001 in)	
	Crankpin oil clearance		0.028–0.052 mm (0.0011–0.0020 in)	0.08 mm (0.003 in)	
	Main journal oil clearance		0.020–0.044 mm (0.0008–0.0017 in)	0.06 mm (0.002 in)	
Cylinder	I.D.		70.000–70.015 mm (2.755–2.756 in)	70.10 mm (2.76 in)	
	Warpage		—	0.10 mm (0.004 in)	
Piston	Ring-to-groove clearance	Top	0.015–0.045 mm (0.0006–0.0018 in)	0.10 mm (0.004 in)	
		Second	0.015–0.045 mm (0.0006–0.0018 in)	0.10 mm (0.004 in)	
	Ring end gap	Top	0.20–0.35 mm (0.008–0.014 in)	0.55 mm (0.022 in)	
		Second	0.20–0.35 mm (0.008–0.014 in)	0.55 mm (0.022 in)	
		Oil (Side rail)	0.20–0.90 mm (0.008–0.035 in)	1.1 mm (0.04 in)	
	Piston O.D.		69.960–69.990 mm (2.754–2.755 in)	69.85 mm (2.750 in)	
	Piston-to-cylinder clearance		0.01–0.055 mm (0.004–0.002 in)	0.10 mm (0.004 in)	
	Piston pin bore		18.002–18.008 mm (0.7087–0.7090 in)	18.06 mm (0.71 in)	
	Piston pin O.D.		17.994–18.000 mm (0.7084–0.7086 in)	17.98 mm (0.70 in)	
	Piston-to-piston pin clearance		0.002–0.014 mm (0.0001–0.0006 in)	0.04 mm (0.002 in)	
	Connecting rod small end I.D.		18.016–18.034 mm (0.7093–0.7100 in)	18.08 mm (0.712 in)	
Piston pin-to-connecting rod clearance		0.016–0.040 mm (0.0006–0.0016 in)	0.060 mm (0.0024 in)		
Cam chain	Length at 13 kg (29 lb) tension		323.85–324.30 mm (12.750–12.767 in)	326.120 mm (12.84 in)	

### TORQUE:

Crankpin: 30–34 N·m (3.0–3.4 kg·m, 22–25 ft·lb)



## **TROUBLESHOOTING**

### **Excessive noise**

1. Crankshaft
  - Worn main bearing
  - Worn rod bearing
2. Piston and Connecting Rod
  - Worn piston or cylinder
  - Worn piston pin or pin hole
  - Worn rod small end

### **Low compression or uneven compression**

1. Worn cylinder or piston ring

### **Excessive smoke**

1. Worn cylinder, piston or piston rings
2. Improperly installed piston rings
3. Damaged piston or cylinder

### **Overheating**

1. Excessive carbon build-up on piston head
2. Blocked or restricted flow of coolant
3. Sticking thermostat

### **Knocking or abnormal noise**

1. Worn pistons and cylinders
2. Excessive carbon build-up on piston head.




## CONNECTING ROD REMOVAL


Separate the crankcase assembly (Section 11).

Check the connecting rod side clearance.

**SERVICE LIMIT: 0.40 mm (0.016 in)**




Remove the connecting rod bearing caps and note their locations.



Push the connecting rods and pistons out through the top of the cylinder bores.

### CAUTION

*On engines with high mileage, inspect the cylinders for a ridge just above the highest point of ring travel. Any ridge must be removed with an automotive type ridge reamer before removing the pistons to allow the pistons and rings to pass through the cylinder.*





## CRANKSHAFT/PISTON


Mark the rods, pistons, bearings and caps as you remove them to indicate the correct cylinder and position on the crankpins.



## PISTON REMOVAL

Remove the piston pin clips. Push the piston pin out and remove the piston.

Mark the piston pins to indicate their correct piston position.



## PISTON/PISTON RING INSPECTION

Measure the piston ring-to-groove clearance.

**SERVICE LIMIT: 0.10 mm (0.004 in)**  
**(TOP/SECOND)**

Remove the piston rings and mark them to indicate the correct cylinder and piston position.

Clean the piston crown, removing all carbon deposits.

Inspect the piston for cracks or other damage and the ring grooves for excessive wear and carbon build-up.






Using a piston, push the ring into the cylinder squarely and measure the end gap.

**SERVICE LIMITS:**

- TOP:** 0.55 mm (0.022 in)
- SECOND:** 0.55 mm (0.022 in)
- OIL (Side rail):** 1.1 mm (0.04 in)



Measure the piston O.D.

**NOTE:**

Take measurements 10 mm (0.4 in) from the bottom, and 90° to the piston pin hole.

**SERVICE LIMIT: 69.85 mm (2.750 in)**



Inspect the cylinder bores for wear or damage. Measure the cylinder I.D. at three levels in X and Y axis.


**SERVICE LIMIT: 70.10 mm (2.76 in)**

Calculate the piston-to-cylinder clearance.

**SERVICE LIMIT: 0.10 mm (0.004 in)**

Oversize pistons are available in the following sizes:

**0.25, 0.50, 0.75 and 1.00 mm**



Measure each piston pin hole I.D.

**SERVICE LIMIT: 18.06 mm (0.71 in)**



Measure each piston pin O.D.

**SERVICE LIMIT: 17.98 mm (0.70 in)**

Calculate the piston pin-to-piston clearance.

**SERVICE LIMIT: 0.04 mm (0.002 in)**



Measure the connecting rod small end I.D. If the reading exceeds the service limit, replace the rod.


**SERVICE LIMIT: 18.08 mm (0.712 in)**





## CRANKSHAFT REMOVAL

Remove the crankshaft and cam chains.




## CRANKSHAFT INSPECTION

Set the crankshaft on a stand or Vee blocks.  
Set a dial indicator on the center main bearing journal. Rotate the crankshaft two revolutions and read the runout.

Actual runout is 1/2 of the total indicator reading.

**SERVICE LIMIT: 0.03 mm (0.001 in)**



## CAM CHAIN LENGTH INSPECTION

Place the cam chain on the camshaft sprockets with the index lines positioned as indicated. Secure one camshaft sprocket and apply 13 kg (29 lbs) of tension to the other.


Then measure the distance between the index lines as shown.

**SERVICE LIMIT: 326.120 mm (12.84 in)**

### NOTE

The index lines should be parallel to each other.

Replace the cam chain if it is longer than the service limit.







**CRANKSHAFT/PISTON**

**BEARING INSPECTION**

**MAIN BEARING**


Inspect the bearing inserts for unusual wear or damage.

Reinstall the upper crankcase's main bearing inserts, then carefully lower the crankshaft in place.

Wipe all oil from the bearing inserts and journals. Put a piece of plastigauge on each journal.

**NOTE**

Do not put the plastigauge over the oil hole in the main bearing journal of the crankshaft.



PLASTIGAUGE

Install the main bearings on the correct journals in the lower crankcase, then assemble and tighten the bolts evenly in 2-3 steps in the sequence shown.


**TORQUE VALUES:**

6 mm bolt: 10-14 N·m (1.0-1.4 kg·m, 7-10 ft·lb)

9 mm bolt: 30-34 N·m (3.0-3.4 kg·m, 22-25 ft·lb)

**NOTE:**


Do not rotate the crankshaft during inspection.



Remove the lower crankcase and measure the compressed plastigauge on each journal.

**OIL CLEARANCE SERVICE LIMIT:**

0.06 mm (0.002 in)






**CRANKSHAFT/PISTON**

Inspect the bearing inserts for unusual wear or damage.

Wipe all oil from the bearing inserts and crankpins. Put a piece of plastigauge on each crankpin.

**NOTE**

- Do not put the plastigauge over the oil hole in the crankpin.
- The bearing tabs should face toward the exhaust ports. Remember the front and rear cylinder exhaust ports face opposite directions.




Install the bearing caps and rods on the correct crankpins, and tighten them evenly.

**TORQUE: 30–34 N·m (3.0–3.4 kg·m, 22-25 ft·lb)**


**NOTE**

Do not rotate the crankshaft during inspection.



Remove the caps and measure the compressed plastigauge on each crankpin.

**OIL CLEARANCE SERVICE LIMIT:**  
**0.08 mm (0.003 in)**




## BEARING SELECTION


### CONNECTING ROD BEARING

If rod bearing clearance is beyond tolerance, select replacement bearings as follows:

The code numbers (1, 2, or 3) stamped on each connecting rod identifies its inside diameter (I.D.).



The code letters (A, B, or C) stamped on each crankshaft counter weight identifies the outside diameter (O.D.) of its crankpin.




Cross reference the crankpin and rod codes to select the correct replacement bearing.

		CRANKPIN O.D. CODE LETTER			
		A	B	C	
		35.992– 36.000 mm	35.984– 35.992 mm	35.976– 35.984 mm	
CONNECTING ROD I.D. CODE NO.	1	39.000– 39.008 mm	E (Yellow)	D (Green)	C (Brown)
	2	39.008– 39.016 mm	D (Green)	C (Brown)	B (Black)
	3	39.016– 39.024 mm	C (Brown)	B (Black)	A (Blue)

#### BEARING INSERT THICKNESS:


- A (Blue): 1.502–1.506 mm (0.0591–0.0593 in)
- B (Black): 1.498–1.502 mm (0.0590–0.0591 in)
- C (Brown): 1.494–1.498 mm (0.0588–0.0590 in)
- D (Green): 1.490–1.494 mm (0.0587–0.0588 in)
- E (Yellow): 1.486–1.490 mm (0.0585–0.0587 in)





**MAIN BEARING**

The code letters (A, B, or C) stamped on the rear portion of the upper crankcase identifies the inside diameter (I.D.) of each main bearing journal, from left-to-right. In this example, the I.D. code for the right main journal is "A".




I.D. CODE LETTERS

The code numbers (1, 2, or 3) stamped on each crankshaft counter weight identifies the outside diameter (O.D.) of its main journal. Cross reference the crankcase and crank journal codes to select the correct replacement bearing.

SELECTION TABLE (ENGINE No. ~ RC15E 2001586)

Unit : mm (in)

MAIN JOURNAL O.D. CODE NUMBER		1	2	3
CASE I.D. CODE LETTERS		35.992-36.000 (1.4170- 1.4173)	35.984-35.992 (1.4167- 1.4170)	35.976-35.984 (1.4164- 1.4167)
A	39.000-39.008 (1.5354-1.5357)	D (Green)	C (Brown)	B (Black)
B	39.008-39.016 (1.5357-1.5361)	C (Brown)	B (Black)	A (Blue)
C	39.016-39.024 (1.5361-1.5364)	B (Black)	A (Blue)	A (Blue)



O.D. CODE NUMBERS


SELECTION TABLE (ENGINE NO. RC15E 2001587 ~ )

Unit : mm (in)

MAIN JOURNAL O.D. CODE NUMBER		1	2	3
CASE I.D. CODE LETTERS		36.000-36.008 (1.4173- 1.4176)	35.992-36.000 (1.4170- 1.4173)	35.984-35.992 (1.4167- 1.4170)
A	39.000-39.008 (1.5354-1.5357)	E (Yellow)	D (Green)	C (Brown)
B	39.008-39.016 (1.5357-1.5361)	D (Green)	C (Brown)	B (Black)
C	39.016-39.024 (1.5361-1.5364)	C (Brown)	B (Black)	A (Blue)

**MAIN BEARING INSERT THICKNESS:**

- A (Blue): 1.506-1.510 mm (0.0593-0.0594 in)
- B (Black): 1.502-1.506 mm (0.0591-0.0593 in)
- C (Brown): 1.498-1.502 mm (0.0590-0.0591 in)
- D (Green): 1.494-1.498 mm (0.0588-0.0590 in)
- E (Yellow): 1.490-1.494 mm (0.0587-0.0588 in)



COLOR CODE



**CRANKSHAFT/PISTON**

**CRANKSHAFT INSTALLATION**


Install the main bearings into the upper crankcase. Apply molybdenum disulfide grease to the upper and lower main bearings. Install the crankshaft with the cam chains.



The weight code is stamped on the connecting rod by the alphabetical code. When replacing the connecting rod, perform the weight selection between the No. 1 and 2 connecting rods, or No. 3 and 4 connecting rods in accordance with the selection table.

**NOTE:**

- It is not necessary to perform the weight selection between the No. 1 and 3, or No. 2 and 4 connecting rods.
- The "o" mark in the table indicates that the matching is possible in the crossed codes.
- The cylinders are arranged in the order of No. 1, 2, 3, 4 from the alternator side.



**SELECTION TABLE**

#1, #2 CONNECTING RODS						#3, #4 CONNECTING RODS					
#1 ROD CODE \ #2 ROD CODE						#3 ROD CODE \ #4 ROD CODE					
	A	B	C	D	E		A	B	C	D	E
A				○	○	A				○	○
B			○	○	○	B			○	○	○
C		○	○	○		C		○	○	○	○
D	○	○	○			D	○	○	○		
E	○	○				E	○	○			




## PISTON AND ROD INSTALLATION

Clean the piston domes, ring lands, and skirts.  
Carefully install the piston rings onto the piston.  
Stagger the ring end gaps as shown.

**NOTE:**

- Be careful not to damage the piston and piston rings during assembly.
- All rings should be installed with the markings facing up.
- After installing the rings they should rotate freely, without sticking.



Coat the rod's small end with molybdenum disulfide grease.

**Rear cylinders:**

Note that the rear cylinder connecting rods are marked "MB0-F" or "MB2-R" for the VF750F, and "MB1-F" for the VF700.

Install the pistons on the rear connecting rods so that the intake "IN" mark is facing opposite the oil hole in the rod.


**REAR CYLINDER "IN" MARK**



**IDENTIFICATION MARK**

VF750F shown.

VF700F:  
MB1-F





**CRANKSHAFT/PISTON**

**Front cylinders:**

Note that the front cylinder connecting rods are marked "MB0-R" or "MB2-F" for the VF750F, and "MB1-R" for the VF700.

Install the pistons on the front rods so that the intake "IN" mark is facing the same direction as the oil hole in the rod.

**NOTE:**

- Do not interchange the pistons, piston pins or connecting rods.
- Make sure that the piston pin clips are properly seated.


FRONT CYLINDER "IN" MARK



IDENTIFICATION MARK

VF750F shown.

VF700F:  
MB1-R




OIL HOLES

Align the hole in the connecting rod bearing insert with the hole in the connecting rod and install the insert.



OIL HOLE

Install the connecting rod cap bearing insert. Apply molybdenum disulfide grease to the connecting rod bearings.



CONNECTING ROD BEARING




Coat the cylinders, piston rings/grooves and piston with oil. To prevent damaging the crankshaft, slip short sections of rubber hose over the rod bolts before installation.

Install the rod and piston assemblies into the cylinders from the top of the crankcase. Be sure each assembly is returned to its original position as noted during removal.

**NOTE**

The piston intake "IN" marks should be facing each other as shown.



Compress the piston rings with a ring compressor and insert the piston and rod into the cylinder until the rod seats on the crankpin.

**NOTE**

Be careful not to damage the pistons or rings during assembly.



Flip the upper crankcase over.

Install and torque the connecting rod caps.

**TORQUE: 30–34 N·m (3.0–3.4 kg·m, 22–25 ft·lb)**


**NOTE**

- Be sure the bearing caps are installed in their correct location as marked during removal.
- Tighten the nuts in two or more steps.
- After tightening the bolts, check that the rods move freely without binding.

Assemble the crankcase (See page 11-3).








21-25 N·m  
(2.1-2.5 kg-m, 15-18 ft-lb)

16-20 N·m  
(1.6-2.0 kg-m, 12-14 ft-lb)





SERVICE INFORMATION	13-1
TROUBLESHOOTING	13-2
TRANSMISSION DISASSEMBLY	13-3
SHIFT FORK AND SHIFT DRUM	13-6
TRANSMISSION ASSEMBLY	13-9

## SERVICE INFORMATION

### GENERAL

- The gearshift linkage can be serviced with the engine in the frame (Section 8).
- For internal transmission repairs, the crankcase must be separated (Section 11).

### SPECIFICATIONS

			STANDARD	SERVICE LIMIT
Transmission	Backlash	1st	0.047–0.142 mm (0.0019–0.0056 in)	0.20 mm (0.008 in)
		2nd	0.064–0.128 mm (0.0025–0.0050 in)	0.17 mm (0.007 in)
		3rd, 4th, 5th	0.068–0.136 mm (0.0027–0.0054 in)	0.18 mm (0.007 in)
	Gear I.D.	M4, M5 gear	28.000–28.021 mm (1.1024–1.1032 in)	28.04 mm (1.104 in)
		C1 gear	26.000–26.021 mm (1.0236–1.0244 in)	26.04 mm (1.025 in)
		C2, C3 gear	31.000–31.025 mm (1.2205–1.2215 in)	31.04 mm (1.222 in)
	Gear bushing O.D.	M4, M5 gear	27.959–27.980 mm (1.1007–1.1016 in)	27.94 mm (1.100 in)
		C1 gear	25.959–25.980 mm (1.0220–1.0228 in)	25.94 mm (1.021 in)
		C2, C3 gear	30.950–30.975 mm (1.2185–1.2195 in)	30.93 mm (1.218 in)
	Gear bushing I.D.	M4	24.995–25.016 mm (0.9840–0.9849 in)	25.04 mm (0.986 in)
		C1	22.020–22.041 mm (0.8669–0.8678 in)	22.06 mm (0.869 in)
	Mainshaft O.D. (at M4)		24.977–24.990 mm (0.9833–0.9839 in)	24.92 mm (0.981 in)
	Countershaft O.D. (at C1)		21.979–22.000 mm (0.8653–0.8661 in)	21.96 mm (0.865 in)
	Gear-to-bushing clearance	M4, M5	0.020–0.062 mm (0.0008–0.0024 in)	0.10 mm (0.004 in)
		C1	0.020–0.062 mm (0.0008–0.0024 in)	0.10 mm (0.004 in)
C2, C3		0.025–0.075 mm (0.0010–0.0030 in)	0.11 mm (0.004 in)	
Bushing-to-shaft clearance	M4	0.005–0.047 mm (0.0002–0.0019 in)	0.06 mm (0.002 in)	
	C1	0.020–0.062 mm (0.0008–0.0024 in)	0.10 mm (0.004 in)	
Shift fork	Claw thickness		6.43–6.50 mm (0.253–0.256 in)	6.1 mm (0.24 in)
	I.D.	Left and right	14.000–14.021 mm (0.5512–0.5520 in)	14.04 mm (0.553 in)
Fork shaft	O.D.		13.966–13.984 mm (0.5498–0.5505 in)	13.90 mm (0.547 in)



## TRANSMISSION

---

### TORQUE VALUES

Countershaft bearing holder	21–25 N·m (2.1–2.5 kg-m, 15–18 ft-lb)
Shift fork center	16–20 N·m (1.6–2.0 kg-m, 12–14 ft-lb)

### TOOLS

#### Common

Driver	07746-0030100	}	or Driver	07945-3710200
Attachment, 25 mm	07746-0030200			

## TROUBLESHOOTING

#### Hard to shift

1. Clutch slave cylinder sticking
2. Shift fork bent
3. Shift shaft bent
4. Shift claw bent
5. Shift drum cam grooves damaged

#### Transmission jumps out of gear

1. Gear dogs worn
2. Shift shaft bent
3. Shift drum stopper broken
4. Shift forks bent




## TRANSMISSION DISASSEMBLY


Separate the crankcase (Section 11).  
Remove the dowel pins from the crankcase.  
Inspect the backlash of each gear.

**SERVICE LIMIT:**


- 1st: 0.20 mm (0.008 in)
- 2nd: 0.17 mm (0.007 in)
- 3rd, 4th, 5th: 0.18 mm (0.007 in)



Remove the mainshaft.




Remove the countershaft bearing holder bolts.



## TRANSMISSION

Pull the countershaft out of the crankcase while removing C1, C4, C2, C3, and the spline washers and bushings.



### TRANSMISSION INSPECTION

Check gear dogs, dog holes and gear teeth for excessive or abnormal wear, or evidence of insufficient lubrication.

Measure the I.D. of each gear.

**SERVICE LIMIT:**

M4, M5 gear:	28.04 mm (1.104 in)
C1 gear:	26.04 mm (1.025 in)
C2, C3 gear:	31.04 mm (1.222 in)



Measure the O.D. of the gear bushings.

**SERVICE LIMIT:**

M4, M5:	27.94 mm (1.100 in)
C1:	25.94 mm (1.021 in)
C2, C3:	30.93 mm (1.218 in)

Calculate the clearance between the gear bushings and the gears.

**SERVICE LIMIT:**

M4, M5:	0.10 mm (0.004 in)
C1:	0.10 mm (0.004 in)
C2, C3:	0.11 mm (0.004 in)





Measure the I.D. of the gear bushings.

**SERVICE LIMIT:**

- M4 gear bushing: 25.04 mm (0.986 in)
- C1 gear bushing: 22.06 mm (0.869 in)



Measure the O.D. of the mainshaft and countershaft.


**SERVICE LIMIT:**

- Mainshaft (at M4 bushing):  
24.92 mm (0.981 in)
- Countershaft (at C1 bushing):  
21.96 mm (0.865 in)

Calculate the clearance between the bushing and shaft.

**SERVICE LIMIT:**

- M4 bushing-to-shaft: 0.06 mm (0.002 in)
- C1 bushing-to-shaft: 0.10 mm (0.004 in)




**TRANSMISSION**

**SHIFT FORK AND SHIFT DRUM**

**REMOVAL**

Bend the lock washer tab down and remove the center fork mounting bolt.  
Remove the shift fork shaft and shift forks.




Remove the bearing stopper plates.

Remove the shift drum.




**GEAR SHIFT DRUM AND SHIFT FORK INSPECTION**

Inspect the shift drum end for scoring, scratches, or evidence of insufficient lubrication.  
Check the shift drum grooves for damage.





Inspect the shift drum hole and shift fork shaft hole for scoring or scratches.



Measure the shift fork shaft O.D. at right and left shift fork surfaces.  
Check for scratches, scoring or evidence of insufficient lubrication.

**SERVICE LIMIT: 13.90 mm (0.547 in)**



Measure the right and left shift fork I.D.

**SERVICE LIMITS:**


**I.D. (right and left fork): 14.04 mm (0.553 in)**






Measure the shift fork claw thickness.

**SERVICE LIMIT: 6.1 mm (0.24 in)**



### INSTALLATION

Install the shift drum.  
Apply a locking agent to the screw threads and install the bearing stopper plates.




Install the shift fork shaft so that the oil hole end is toward the right.

Install the shift forks onto the shaft.  
Install a new lock washer and the bolt to the center shift fork and tighten the bolt.

**TORQUE: 16–20 N·m (1.6–2.0 kg·m, 12–14 ft·lb)**

Bend up the lock washer's tabs.






## TRANSMISSION ASSEMBLY

### MAINSHAFT

Install the mainshaft bearing with the special tools.




Check the gears for freedom of movement or rotation on the shaft.  
Check that the snap rings are seated in the grooves.




COUNTERSHAFT

Before installing the countershaft in the crankcase, install the C5 gear and snap ring.



Install the C3 gear and spline collar.  
Install the stopper washer while aligning the tab of the stopper washer with the groove in the spline collar.

Assemble the C2, C4 and C1 gears, washers and collars.







Install the countershaft bearing holder bolts and tighten them.

**TORQUE: 21–25 N·m (2.1–2.5 kg·m, 15–18 ft·lb)**

COUNTERSHAFT BEARING HOLDER




Check that the oil orifice is clear.




OIL ORIFICE

Install the mainshaft, then reassemble the upper and lower crankcase (see Section 11).

MAINSHAFT







SERVICE INFORMATION	14-1	IGNITION SWITCH	14-6
TROUBLESHOOTING	14-2	HANDLEBARS	14-7
HEADLIGHT	14-3	FRONT WHEEL	14-11
INSTRUMENTS	14-3	FRONT FORKS	14-18
FUSE HOLDER REPLACEMENT	14-5	STEERING STEM	14-31

## SERVICE INFORMATION

### GENERAL

A jack or other support is required to support the front of the motorcycle when you are working on the front wheel or fork.

### SPECIFICATIONS

		STANDARD	SERVICE LIMIT
Axle shaft runout		—	0.2 mm (0.01 in)
Front wheel rim runout	Radial	—	2.0 mm (0.08 in)
	Axial	—	2.0 mm (0.08 in)
Fork spring free length		479.3 mm (18.87 in)	470 mm (18.5 in)
Fork tube runout		—	0.2 mm (0.01 in)
Front fork fluid capacity	Right	VF750F: 360 cc (12.2 oz), VF700F: 350 cc (11.9 oz) After '84 VF700F: 350 cc (11.9 oz)	—
	Left	VF750F: 380 cc (12.8 oz), VF700F: 370 cc (12.5 oz) After '84 VF700F: 375 cc (12.7 oz)	—
Front fork air pressure		0—40 kPa (0—0.4 kg/cm <sup>2</sup> , 0—6 psi)	—

### TORQUE VALUES

Steering stem nut	90—120 N·m (9.0—12.0 kg-m, 65—87 ft-lb)
Steering bearing adjustment nut	'83: 10—12 N·m (1.0—1.2 kg-m, 7—9 ft-lb) After '83: 19—23 N·m (1.9—2.3 kg-m, 14—17 ft-lb)
Fork bridge pinch bolt	30—40 N·m (3.0—4.0 kg-m, 22—29 ft-lb)
Front axle holder	18—25 N·m (1.8—2.5 kg-m, 13—18 ft-lb)
Front axle nut	55—65 N·m (5.5—6.5 kg-m, 40—47 ft-lb)
Fork top pinch bolts	9—13 N·m (0.9—1.3 kg-m, 7—10 ft-lb)
Fork bottom pinch bolts	45—55 N·m (4.5—5.5 kg-m, 33—40 ft-lb)
Handlebar pinch bolts	30—40 N·m (3.0—4.0 kg-m, 22—29 ft-lb)
Front brake caliper mount bolts	30—40 N·m (3.0—4.0 kg-m, 22—29 ft-lb)
Anti-dive piston pin bolt	20—25 N·m (2.0—2.5 kg-m, 14—18 ft-lb)
Front brake disc	35—40 N·m (3.5—4.0 kg-m, 25—29 ft-lb)



## FRONT WHEEL/SUSPENSION

---

### TOOLS

#### Special

Hex. wrench, 6 mm	07917-3230000 or equivalent
Snap ring pliers	07914-3230001 or equivalent in U.S.A.
Fork seal driver	07947-4630100
Steering stem socket	07916-3710100
Bearing race remover	07946-3710500
Ball race remover	07953-4250002
Steering stem driver	07946-MB00000 or $\left\{ \begin{array}{l} \text{Steering stem driver 07946-3710601} \\ \text{Attachment 07964-MB00200} \end{array} \right.$

#### Common

Driver	07749-0010000
Attachment, 42 x 47 mm	07746-0010300
Pilot, 15 mm	07746-0040300
Lock nut wrench, 30 x 32 mm	07716-0020400 or equivalent in U.S.A.
Extension	07716-0020500 or equivalent in U.S.A.
Attachment, 52 x 55 mm	07746-0010400
Bearing remover shaft	07746-0050100 or equivalent in U.S.A.
Bearing remover head, 15 mm	07746-0050400 or equivalent in U.S.A.

## TROUBLESHOOTING

#### Hard steering

1. Steering bearing adjustment nut too tight
2. Faulty steering stem bearings
3. Damaged steering stem bearings
4. Insufficient tire pressure

#### Steers to one side or does not track straight

1. Bent forks
2. Bent front axle
3. Wheel installed incorrectly

#### Front wheel wobbling

1. Bent rim
2. Worn front wheel bearings
3. Faulty tire
4. Axle nut tightened improperly

#### Soft suspension

1. Weak fork springs
2. Insufficient fluid in forks
3. Fork air pressure incorrect

#### Hard suspension

1. Incorrect fluid weight in forks
2. Fork air pressure incorrect
3. Bent fork tubes
4. Clogged fluid passage
5. Clogged anti-dive orifice

#### Front suspension noise

1. Worn slider or guide bushings
2. Insufficient fluid in forks
3. Loose front fork fasteners
4. Lack of grease in speedometer gearbox



## HEADLIGHT

### REMOVAL/INSTALLATION

Remove the fairing.




FAIRING

Remove the headlight rim and headlight by removing the three screws.

Disconnect the headlight coupler.

Install the headlight in the reverse order of removal.

Check the headlight aim and adjust it if necessary (page 3-17).



HEADLIGHT RIM

## INSTRUMENTS

### REMOVAL

Remove the fairing.

Remove the headlight with its bracket by removing the mount bolt and nuts.






## FRONT WHEEL/SUSPENSION

Disconnect the instrument wire coupler and the speedometer cable.

Remove the mount nuts and remove the instrument assembly from the bracket.



SPEEDOMETER CABLE

INSTRUMENT WIRE  
COUPLER


## DISASSEMBLY

Remove the odometer reset knob.



ODOMETER RESET KNOB

Remove the instrument pod from the instrument panel.  
Remove the instrument bulb sockets.  
Replace any burnt bulbs.  
If the bulb does not light, inspect the wiring for an open or short circuit.



INSTRUMENT PANEL



**INSTRUMENT ASSEMBLY/  
INSTALLATION**

Assemble and install the instruments in the reverse order of disassembly and removal.

**FUSE HOLDER REPLACEMENT**

Remove the headlight bracket (page 14-3).  
Disconnect the fuse holder wire coupler.  
Remove the fuse holder cover.



Remove the two attaching screws and remove the fuse holder from the fork bridge.


Install the fuse holder in the reverse order of removal.

**NOTE**

Be sure to rout the fuse holder wire properly (pages 1-10 thru 1-12).

'83-'84:

After '84



## IGNITION SWITCH

### REMOVAL/INSTALLATION


Remove the headlight and the instruments (page 14-3).

Remove the fuse holder cover.

Disconnect the ignition switch wire coupler.


Remove the ignition switch mounting bolts, and remove the ignition switch.

Install the ignition switch in the reverse order of removal.




### DISASSEMBLY/ASSEMBLY

Pry open the retainer.




Insert the ignition key and turn it so it is partway between the ON and OFF detent positions.






Push in the lugs, that are locked in the slots, then pull the contact base from the switch. Assemble the ignition switch in the reverse order of disassembly.




## HANDLEBARS

### REMOVAL

Disconnect the front brake switch wires.  
Remove the front brake master cylinder.



Remove the right handlebar switch.




**FRONT WHEEL/SUSPENSION**


Disconnect the clutch switch wires.  
Remove the clutch master cylinder.



Remove the left handlebar switch.




Disconnect the choke cable from the choke lever.



CHOKE CABLE



Remove the left and right handlebar retainer rings.  
Loosen the left and right handlebar pinch bolts.  
Remove the handlebars from the fork tubes.  
Remove the throttle grip from the right handlebar.



### INSTALLATION

Apply grease to the throttle grip sliding surface and slide the throttle grip over the handlebar.




Install the handlebars onto the fork tubes and on the handlebar spacers, aligning the pin on the bottom of the handlebar with the hole in the spacer.

Tighten the handlebar pinch bolts.

**TORQUE: 30–40 N·m (3.0–4.0 kg·m, 22–29 ft·lb)**

Install the handlebar retainer rings.




## FRONT WHEEL/SUSPENSION

Align the right handlebar switch locating pin with the hole in the handlebar and install the right handlebar switch.


Install the top portion of the switch and tighten its screws.

Tighten the forward screw first, then tighten the rear screw.



Place the front brake master cylinder on the handlebar and install the master cylinder holder with the "UP" mark facing up.


Align the index mark on the holder with the punch mark on the handlebar, and tighten the upper bolt first then tighten the lower bolt.



Connect the choke cable to the choke lever.

Align the left handlebar switch locating pin with the hole in the handlebar and install the left handlebar switch.

Tighten the upper screw first, then tighten the lower screw.






Place the clutch master cylinder on the handlebar and install the master cylinder holder with the "UP" mark facing up.

Align the index mark on the holder with the punch mark on the handlebar, and tighten the upper bolt

Connect the clutch switch wires.




## FRONT WHEEL

### REMOVAL

Remove the right front brake caliper from the fork leg. Remove the right axle holder.

### NOTE


If you squeeze the front brake lever after the caliper is removed, the caliper piston will move out and make reassembly difficult.



Remove the speedometer cable set screw and disconnect the speedometer cable.

Remove the left front caliper from the fork leg and anti-dive piston case.

Remove the left axle holder.






**DISASSEMBLY**

Remove the front axle nut and axle.



Remove the spacer from the right side.  
Remove the speedometer gear box from the left side.



Remove the left and right brake disc mounting bolts and discs.


Remove the dust seal from both sides.  
Remove the speedometer rainer from the left side.





### WHEEL BEARING INSPECTION

Check wheel bearing play by placing the wheel in a truing stand and spinning the wheel by hand. Replace the bearings with new ones if they are noisy or have excessive play.



### WHEEL INSPECTION

Check the rim runout by placing the wheel in a truing stand. Spin the wheel slowly and read the runout using a dial indicator.


**SERVICE LIMITS:**

**RADIAL RUNOUT: 2.0 mm (0.08 in)**

**AXIAL RUNOUT: 2.0 mm (0.08 in)**

**NOTE**


The wheel cannot be repaired and must be replaced with a new one if the service limits are exceeded.



### AXLE INSPECTION

Set the axle in V blocks and measure the runout.

**SERVICE LIMIT: 0.2 mm (0.01 in)**





**FRONT WHEEL/SUSPENSION**

BEARING REMOVER SHAFT  
07746-0050100

**WHEEL BEARING REMOVAL**

If the bearing need replacement, remove the bearings and distance collar.

**NOTE**

Never reinstall old bearings; once the bearings are removed, they must be replaced with new ones.




BEARING REMOVER HEAD  
07746-0050400

**ASSEMBLY**

**WARNING**

*Do not get grease on the brake disc or stopping power will be reduced.*



**NOTE**

- The cast wheel has no rim band.
- The front wheel uses a tubeless tire. For tubeless tire repair, refer to the Honda Tubeless Tire Manual.




Pack all bearing cavities with grease.  
Drive in the right bearing first, sealed side facing out, then press the distance collar into place.

**NOTE**


Be certain the distance collar is in position before installing the left bearing.

Drive in the left bearing squarely, making sure that it is fully seated and that the sealed side is facing out.



ATTACHMENT, 42 x 47 mm 07746-0010300  
PILOT, 15 mm 07746-0040300


Install the speedometer gear retainer in the left side of the wheel hub, aligning its tangs with the slots in the hub.



Align

Install the left dust seal.  
Place new gaskets on the disc mounting flange, then install the left disc with its "L" mark facing out.  
Tighten the disc mounting bolts.

**TORQUE 35-40 N·m (3.5-4.0 kg·m, 25-29 ft·lb)**



DUST SEAL




**FRONT WHEEL/SUSPENSION**

Install the right dust seal.


Place new gaskets on the disc mounting flange, then install the right disc with its "R" mark facing out. Tighten the mounting bolt to the same torque as left side.

Install the spacer.



Fill the speedometer gearbox with grease and install the plain washer and drive gear.

Install the speedometer gearbox in the wheel hub, aligning the tangs with the slots.



Install the front axle and axle nut. Tighten the axle nut.

**TORQUE: 55–65 N·m (5.5–6.5 kg·m, 40–47 ft·lb)**

**NOTE**

There are flats on the opposite end of the axle, so you can hold the axle while torquing the axle nut.



Clean the brake discs with a high quality degreasing agent.




**INSTALLATION**

Position the wheel between the fork legs.  
Lower the engine so the fork legs rest on the top of the axle.

Position the tang on the speedometer gear box against the lug on the left fork leg.

Install the axle holders with the arrow pointing forward.



Install the right front caliper and tighten the mount bolts.

**TORQUE: 30–40 N·m (3.0–4.0 kg·m, 22–29 ft·lb)**

Tighten the right axle holder nuts to the specified torque, starting with the forward nut.

**TORQUE: 18–25 N·m (1.8–2.5 kg·m, 13–18 ft·lb)**


Install the left front caliper.  
Tighten the anti-dive pivot bolt.

**TORQUE: 20–25 N·m (2.0–2.5 kg·m, 14–18 ft·lb)**

Tighten the caliper mount bolt.

**TORQUE: 30–40 N·m (3.0–4.0 kg·m, 22–29 ft·lb)**

Connect the speedometer cable and secure it with the set screw.




Measure the clearance between each surface of the left brake disc and the left caliper holder with a 0.7 mm (0.028 in) feeler gauge. If the gauge inserts easily, tighten the forward left axle holder nut to the specified torque, then tighten the rear nut.

If the feeler gauge cannot be inserted easily, pull the left fork out or push it in until the gauge can be inserted.

After installing the wheel, apply the brake several times, then recheck both discs for caliper holder to disc clearance.

**WARNING**

*Failure to provide adequate disc to caliper holder clearance may damage the brake disc and impair brake efficiency.*



**FRONT WHEEL/SUSPENSION****FRONT FORKS****REMOVAL**

Remove the following parts:


- fairing.
- headlight.
- instruments.
- handlebars.
- front wheel.
- handlebar spacers.

**HANDLEBAR SPACERS**

Remove the front fender and fork brace.

**FORK BRACE****FRONT FENDER**

Loosen the fork upper and lower pinch bolts.

**UPPER PINCH BOLTS****LOWER PINCH BOLTS**




Pull each fork tube out of the top bridge.

**NOTE**

Because of the friction caused by the air joint O-rings, you'll have to turn the tubes while pulling down.

Remove the fork stop rings.



**FORK STOP RING**

Pull each fork tube out of the fork bottom bridge.



If replacement of the air joint is necessary, remove the two screws which attach the fork air joint to the top bridge.






**DISASSEMBLY**


Hold the fork tube in a vise, with soft jaws or a shop towel and remove the fork tube cap.

**CAUTION**

*Do not damage the sliding surface.*



Remove the fork spring, spacer and washer. Drain the fork fluid by pumping the fork up and down several times.



Hold the fork slider in a vise with soft jaws or a shop towel. Remove the socket bolt with a hex wrench.

**NOTE**

Temporarily install the spring and fork cap if difficulty is encountered in removing the socket bolt.

The piston and rebound spring can be removed from the right fork.





**'83-'84:**

Remove the dust seal, foam seal and plastic washer.

Discard the foam seal and plastic washer. Do not reuse or replace.

**After '84:**


Remove the dust seal.



'83-'84 Shown

Remove the snap ring.

SNAP RING PLIERS 07914—3230001  
OR EQUIVALENT IN U.S.A.



SNAP RING

Pull the fork tube out until resistance from the slider bushing is felt. Then move it in and out, tapping the bushing lightly until the fork tube separates from the slider. The slider bushing will be forced out by the fork tube bushing.

Remove the oil lock piece from inside the slider.



FORK TUBE

FORK SLIDER




**FRONT WHEEL/SUSPENSION**


Remove the oil seal, back-up ring and slider bushing(s) from the fork tube.

**NOTE**

Do not remove the fork tube bushings unless it is necessary to replace it with a new one.



On the left fork, remove the circlip, oil lock valve, spring, and spring seat from the piston. Remove the piston and rebound spring from the fork tube.




**INSPECTION**

**FORK SPRING FREE LENGTH**

Measure the fork spring free length.

**SERVICE LIMIT: 470 mm (18.5 in)**






**FORK TUBE/FORK SLIDER/PISTON**

Check the fork tube, fork slider and piston for score marks, scratches, or excessive or abnormal wear. Replace any components which are worn or damaged.

Check the fork piston ring for wear or damage.


Check the rebound spring for fatigue or damage.



**FORK TUBE**

Set the fork tube in V blocks and check its runout.


**SERVICE LIMIT: 0.20 mm (0.008 in)**



**BUSHING/BACK-UP RING**

Visually inspect the slider and fork tube bushings. Replace the bushings if there is excessive scoring or scratching, or if the teflon is worn so that the copper surface appears on more than 3/4 of the entire surface.

Check the back-up ring; replace it if there is any distortion at the points shown.






**FRONT WHEEL/SUSPENSION**


**ANTI-DIVE CASE**

Remove the four socket bolts and remove the anti-dive case.

'83-'84:



After '84:




'83-'84:

Remove the piston and spring.  
Remove the boots, pivot bolt collar and stop rubber.


After '84:

Remove the piston and spring.  
Remove the boot, pivot bolt collar and rubber bushing.

'83-'84:



After '84:




Check the spring and piston for wear or damage.

'83-'84:



After '84:






**'83-'84:**

Remove left side washer, stopper ring and orifice.  
Check the orifice for clogging by applying compressed air. Also check the orifice for damage and replace if necessary.  
Remove the check valve setting screw, valve spring and check ball.


**After '84:**

Remove the screw attaching the anti-drive adjuster knob, knob and orifice.  
Remove the check ball screw, spring and ball.  
Check the orifice for clogging, scoring, excessive wear or damage.  
Replace if necessary.

**'83-'84:**




**After '84:**



Assemble the anti-dive case in the reverse order of disassembly.


**NOTE**

Apply a Thread Lock Agent to the threads of the screws and socket bolts before assembly.  
Apply ATF to the piston and piston O-ring.  
Apply silicone grease to the pivot bolt collar.  
Install the pivot bolt collar boot holder as shown.




Check the operation of the collar and piston.

**'83-'84**




**After '84:**





**ASSEMBLY**


Before assembly, wash all parts with a high flash point or non-flammable solvent and wipe them off completely.



Insert the rebound spring and piston into the fork tube.  
On the left fork, install the spring seat, valve spring, oil lock valve and circlip on the piston.  
Place the oil lock piece on the end of the piston.

**NOTE**

On the right fork, install the oil lock piece, aligning the flat sides of the oil lock piece and piston end.





Insert the fork tube into the slider.

**NOTE**

Align the cutout of the oil lock piece with the drain bolt in the slider.

Place the fork slider in a vise with soft jaws or a shop towel.

Apply a locking agent to the socket bolt and thread it into the piston. Tighten with a 6 mm hex wrench.

**NOTE**

Temporarily install the fork spring and fork cap bolt to tighten the socket bolt.


**TORQUE:**

**15–25 N.m (1.5–2.5 kg-m, 11–18 ft-lb)**

Place the slider bushing over the fork tube and rest it on the slider. Put the back-up ring and an old bushing or equivalent tool on top.

Drive the bushing into place with the seal driver and remove the old bushing or equivalent tool.

Coat a new oil seal with ATF and install it with the seal markings facing up. Drive the seal in with the seal driver.



FORK SEAL DRIVER  
07947-4630100




Install the snap ring with its radiused edge facing down and install the dust seal.

**NOTE**

On '83 and '84 do not install the plastic washer or foam seal.

SNAP RING PLIERS  
07914-3230001








## FRONT WHEEL/SUSPENSION

Pour the specified amount of ATF into the fork tube.

	VF750F '84 VF700F	'85 VF700F
RIGHT	360 cc (12.2 oz)	350 cc (11.9 oz)
LEFT	380 cc (12.8 oz)	375 cc (12.5 oz)



Install the fork spring, spring seat and spacer in the fork tube.

### NOTE

Note the spring direction; the closely wound coils must face down in the tube.



Install and torque the fork tube cap.

### NOTE

On the right fork, align the cavity on the damping adjuster rod with the flat side in the piston.

**TORQUE:** 15–30 N·m (1.5–3.0 kg·m, 11–22 ft·lb)

FORK TUBE CAP





**INSTALLATION**

Install the forks and temporarily tighten the bottom pinch bolts.



Install the fork stop rings in the grooves in the fork tube.

Push the fork tubes up until the stop rings contact the air joints.




**FORK STOP RING**

Tighten the bottom pinch bolts.

**TORQUE 45–55 N·m (4.5–5.5 kg·m, 33–40 ft·lb)**

Tighten the top pinch bolts.

**TORQUE: 9–13 N·m (0.9–1.3 kg·m, 7–10 ft·lb)**



**BOTTOM PINCH BOLTS**

## FRONT WHEEL/SUSPENSION


Loosely install the fork brace.

Install the removed parts in the reverse order of removal.

- front fender.
- handlebar spacers.
- handlebars.
- front wheel.
- headlight.
- instruments.
- fairing.

With the front brake applied, pump the forks up and down several times.

Tighten the front fork brace mounting bolts.



Fill the fork tubes with air.

### RECOMMENDER PRESSURE:

0–40 kPa (0–0.4 kg/cm<sup>2</sup>, 0–6 psi)

### CAUTION

- Use only a hand-operated air pump to fill the fork tubes. Do not use compressed air.
- Maximum pressure is 300 kPa (3 kg/cm<sup>2</sup>, 43 psi). Do not exceed this or fork tube component damage may occur.



With the front brake applied, pump the forks up and down several times. Place the motorcycle on its center stand. Check the air pressure and adjust if necessary.



## STEERING STEM

### REMOVAL

Remove the following components.

- fairing.
- headlight.
- instrument.
- handlebars.
- front wheel.
- ignition switch.
- brake hose 3-way joint.



BRAKE HOSE 3-WAY JOINT

LOCK NUT WRENCH, 30 x 32 mm  
07716-0020400 or EQUIVALENT IN U.S.A.

Loosen and remove the steering stem nut.

Remove the forks.



EXTENSION 07716-0020500  
OR EQUIVALENT U.S.A.

Loosen the top bridge pinch bolt and remove the top bridge with the fork air joint.




PINCH BOLT

AIR JOINT




**FRONT WHEEL/SUSPENSION**

Straighten the lock washer tabs and remove the lock nut and lock washer.



Loosen the bearing adjustment nut and remove the steering stem.



Check the steering stem bearings for damage or wear.


**BEARING REPLACEMENT**

**NOTE**

Replace the bearing and bearing race as a set.

Remove the grease retainer.

Remove the bearing inner race and dust seal from the steering stem.





Remove the upper bearing race with the special tool.

**BALL RACE REMOVER**  
07953—4250002



Remove the lower bearing race with the special tool.



**NOTE**

If the motorcycle has been involved in an accident, examine the area around the steering head for cracks.

**BALL RACE REMOVER**  
07953—4250002



**BEARING RACE REMOVER**  
07946—3710500





Drive the upper bearing outer race into the steering head

Drive the lower bearing outer race into the steering head.

DRIVER  
07749-0010000



ATTACHMENT, 42 x 47 mm  
07746-0010300


ATTACHMENT, 52 x 55 mm  
07749-0010400



DRIVER 07749-0010000

Install a dust seal onto the steering stem and press the lower bearing inner race over the stem with the special tool.

STEERING STEM DRIVER  
07946-MB00000 OR  
07946-3710601 AND 07964-MB00200



'83 SHOWN

**INSTALLATION**

Pack the bearing cavities with bearing grease.  
'83: Install the grease retainer on the steering stem, then insert the steering stem into the steering head. Install the bearing retainer and upper bearing/inner race.

After '83: Install the lower bearing and grease retainer onto the steering stem, then insert the steering stem into the steering head. Install the upper bearing and inner race.

UPPER BEARING/  
INNER RACE

'83 SHOWN





Install and tighten the adjusting nut to the specified torque.

**TORQUE:**

- '83: 10–12 N·m (1.0–1.2 kg-m, 7–9 ft-lb)
- '84: 19–21 N·m (1.9–2.1 kg-m, 14–15 ft-lb)

STEERING STEM SOCKET  
07916–3710100



Turn the steering stem lock-to-lock 4–5 times to seat the bearings, then tighten the nut to the same torque.

'83: Again turn the steering stem lock-to-lock 5 times to seat the bearings, then tighten the adjustment nut to the same torque.



Install a new bearing adjustment nut lock washer aligning the tabs with the grooves in the nut. Bend two opposite tabs down into the grooves.

**NOTE**

DO NOT install a used bearing adjustment nut lock washer.

Hand tighten the lock nut. Hold the adjustment nut and further tighten the lock nut only enough to align its grooves with the lock washer tabs.

**NOTE**

If the lock nut grooves cannot be easily aligned with the lock washer tabs, remove the nut, turn it over and reinstall it.

Bend two lock washer tabs up into the lock nut grooves.

LOCK NUT



LOCK WASHER



## FRONT WHEEL/SUSPENSION

Install the top bridge with the fork air joint.  
 Install the front forks (page 14-29).  
 Install and tighten the steering stem nut.

**TORQUE: 90–120 N·m (9.0–12.0 kg·m,  
 65–87 ft·lb)**

EXTENSION  
 07716-0020500 or EQUIVALENT IN U.S.A.



LOCK NUT WRENCH, 30 x 32 mm  
 07716-0020400  
 or EQUIVALENT IN U.S.A.


### STEERING HEAD BEARING PRELOAD

Install the front wheel (page 14-17).  
 Place a stand under the engine and raise the front wheel off the ground.  
 Position the steering stem to the straight ahead position.  
 Hook a spring scale to the fork tube and measure the steering head bearing preload.

#### NOTE

Make sure that there is no cable and wire harness interference.

The preload should be within 1.0–1.6 kg (2.21–3.53 lb) for right and left turns.  
 If the readings do not fall within the range, lower the front wheel and adjust the bearing adjustment nut.  
 After making sure the bearing preload is acceptable, install the removed parts in the reverse order of removal.






MEMO



**REAR WHEEL/SUSPENSION**





SERVICE INFORMATION	15-1
TROUBLESHOOTING	15-2
REAR WHEEL	15-3
SHOCK ABSORBER	15-8
SWINGARM	15-13

## SERVICE INFORMATION

### GENERAL

- The rear wheel uses a tubeless tire. For tubeless tire repairs, refer to the TUBELESS TIRE MANUAL.

### SPECIFICATIONS

		STANDARD	SERVICE LIMIT
Axle runout		—	0.2 mm (0.01 in)
Rear wheel rim runout	Radial	—	2.0 mm (0.08 in)
	Axial	—	2.0 mm (0.08 in)
Shock absorber air pressure		50–300 kPa (0.5–3.0 kg/cm <sup>2</sup> , 7–43 psi)	—

### TORQUE VALUES

Shock arm-to-frame bolts		40–50 N·m (4.0–5.0 kg-m, 29–36 ft-lb)
Shock link-to-shock arm bolt		40–50 N·m (4.0–5.0 kg-m, 29–36 ft-lb)
Rear shock absorber mount bolts		40–50 N·m (4.0–5.0 kg-m, 29–36 ft-lb)
Swingarm pinch bolt		20–30 N·m (2.0–3.0 kg-m, 14–22 ft-lb)
Swingarm pivot bolts		85–105 N·m (8.5–10.5 kg-m, 61–76 ft-lb)
Rear brake torque rod	8 mm	18–25 N·m (1.8–2.5 kg-m, 13–18 ft-lb)
	10 mm	30–40 N·m (3.0–4.0 kg-m, 22–29 ft-lb)
Final driven sprocket		80–100 N·m (8.0–10.0 kg-m, 58–72 ft-lb)
Rear brake disc		35–40 N·m (3.5–4.0 kg-m, 25–29 ft-lb)
Rear axle nut		85–105 N·m (8.5–10.5 kg-m, 61–76 ft-lb)

### TOOLS

#### Special

Needle bearing remover	07931-MA70000
Oil seal driver attachment	07965-MC70100
Oil seal driver attachment ring	07965-ME70100
Oil seal driver	07965-MB00100

#### Common

Attachment, 32 x 35 mm	07746-0010100
Attachment, 37 x 40 mm	07746-0010200
Attachment, 52 x 55 mm	07746-0010400
Attachment, 62 x 68 mm	07746-0010500
Pilot, 17 mm	07746-0040400
Pilot, 20 mm	07746-0040500
Pilot, 25 mm	07746-0040600
Driver	07749-0010000
Bearing remover shaft	07746-0050100 or equivalent in U.S.A.
Bearing remover head, 20 mm	07746-0050600 or equivalent in U.S.A.



## **TROUBLESHOOTING**

### **Oscillation**

1. Bent rim
2. Loose wheel bearings
3. Faulty tire
4. Loose axle
5. Tire pressure incorrect
6. Swingarm bearings worn
7. Worn tires

### **Soft suspension**

1. Weak spring
2. Insufficient fluid in shock absorber
3. Shock absorber air pressure incorrect

### **Hard suspension**

1. Incorrect fluid weight in shock absorber
2. Bent shock absorber
3. Shock absorber air pressure incorrect

### **Suspension noise**

1. Shock case binding
2. Loose fasteners



## REAR WHEEL

### REMOVAL


Place the motorcycle on its center stand.  
Loosen the drive chain adjusting bolts lock nuts and the adjusting bolts.

Remove the axle nut and axle.

Push the wheel forward and remove the drive chain from the driven sprocket and remove the rear wheel.


### NOTE

If you depress the brake pedal after the rear wheel is removed, the caliper piston will move out and make reassembly difficult.



### DISASSEMBLY

Remove the rear brake disc.  
Remove the dust seal.




Remove the final driven sprocket and driven flange together.

### NOTE

Do not separate the driven sprocket and flange, unless replacement of the driven sprocket or flange is necessary.

Remove the dust seal from the final driven flange.




## REAR WHEEL/SUSPENSION

### INSPECTION

#### AXLE


Set the axle in V blocks and read the axle runout with a dial indicator.

**SERVICE LIMIT: 0.2 mm (0.01 in)**



#### REAR WHEEL BEARING

Check the wheel bearing play by rotating the wheel by hand. Replace the bearings with new ones if they are noisy or have excessive play.



#### REAR WHEEL RIM RUNOUT

Check the rim for runout by placing the wheel in a truing stand. Spin the wheel slowly, and read the runout using a dial indicator.


**SERVICE LIMITS:**

**RADIAL RUNOUT: 2.0 mm (0.08 in)**

**AXIAL RUNOUT: 2.0 mm (0.08 in)**

**NOTE**

The wheel cannot be serviced and must be replaced if the above limits are exceeded.






**FINAL DRIVEN SPROCKET**

Check the condition of the final driven sprocket teeth. Replace the sprocket if worn or distorted.


**NOTE**

If the final driven sprocket requires replacement, inspect the drive chain and drive sprocket.



**DAMPER RUBBERS**

Replace the damper rubbers if they are damaged or deteriorated.



**BEARING REPLACEMENT**

Remove the wheel bearings.  
Drive the driven flange side bearing out.

**NOTE**

Never reinstall old bearings; once the bearings are removed, they must be replaced with new ones.

**BEARING REMOVER SHAFT**  
07746-0050100



**BEARING REMOVER HEAD, 20 mm**  
07746-0050600



**REAR WHEEL/SUSPENSION**


Pack all bearing cavities with grease.  
 Press distance collar into place from the left side.

Drive the right bearing in first, then the left bearing with the following tools.

DRIVER	07749-0010000
ATTACHMENT, 52 x 55 mm	07746-0010400
PILOT, 20 mm	07746-0040500

Drive the driven flange bearing in with the following tools.

DRIVER	07749-0010000
ATTACHMENT, 62 x 68 mm	07746-0010500
PILOT, 25 mm	07746-0040600




ATTACHMENT & PILOT

**CAUTION**

*Drive the bearings in squarely with the sealed end facing out, making sure they are fully seated.*

**ASSEMBLY**
**NOTE**

The rear wheel uses a tubeless tire. For tubeless tire repairs, refer to the Tubeless Tire Manual.


**WARNING**

*Do not get grease on the brake disc or stopping power will be reduced.*




Install the rear axle sleeve, final driven flange and driven sprocket.

If the driven sprocket was removed from the flange, tighten the driven sprocket nuts to the specified torque.

**TORQUE: 80–100 N·m (8.0–10.0 kg·m,  
58–72 ft·lb)**

Install the dust seal.




Install the brake disc and tighten the bolts.

**TORQUE: 35–40 N·m (3.5–4.0 kg·m,  
25–29 ft·lb)**

Install the dust seal.



Install the left and right side spacers.



## REAR WHEEL/SUSPENSION

### INSTALLATION

Install the rear wheel in the reverse order of removal.


#### NOTE

- When installing the wheel, carefully fit the brake disc between the brake pads.
- After installing the wheel, apply the brake several times. Then check that the wheel rotates freely. Recheck wheel installation if the brake drags or if the wheel does not rotate freely.

Tighten the rear axle nut.

**TORQUE: 85–105 N·m (8.5–10.5 kg·m,  
61–76 ft·lb)**

Adjust the drive chain slack (page 3-14).



### SHOCK ABSORBER

#### REMOVAL

Place the motorcycle on its center stand.

Remove the seat and left frame side cover.


Remove the breather separator and the electric panel.

BREATHER SEPARATOR




ELECTRIC PANEL

Remove the shock absorber lower mounting bolt. Remove the shock absorber upper mounting bolt, tilt the shock absorber rearward and remove it from the frame by pulling it up.



LOWER MOUNTING BOLT




UPPER MOUNTING BOLT



**OIL SEAL REPLACEMENT**

Remove the shock case boot.

Remove the air valve cap and release the air pressure by depressing the air valve stem.




Press the back-up ring 1.0–2.0 mm (0.04–0.08 in) in with the Oil Seal Driver and attachment.

**CAUTION**

*Do not press in the back-up ring excessively, since it can cause the guide bushing to jam into the shock case, making guide bushing removal difficult.*

Remove the stop ring.



**STOP RING**

Hold the shock absorber upright in a vise.

Fill a high pressure grease gun with ATF (Automatic Transmission Fluid) and connect the attachment hose to the shock absorber air valve. Keep the shock upright.

Wrap a shop towel around the oil seal. Pump ATF into the shock absorber through the attachment hose to force the oil seal and guide bushing out. The ATF will also come out.

Let the shock absorber stand for another 10 minutes to allow all of the ATF to drain from the outer case.

Do not tilt the shock absorber or ATF will flow out of the damper case.



**GREASE GAN FILLED WITH ATF**



**REAR WHEEL/SUSPENSION**

Turn the shock absorber upside down as soon as all the ATF has drained from the outer case.

Fill the damper case with the specified amount of ATF.

**SPECIFIED AMOUNT:**

120 cc (4.06 US oz, 3.38 Imp oz)


**DAMPER OIL**  
 (ATF OR EQUIVALENT)


Install the guide bushing into the damper case.

To prevent seal damage, wrap a piece of tape around the groove at the end of the shock absorber.

Dip the oil seal in ATF and install it onto the damper.


**CAUTION**

*Be careful not to damage the oil seal during installation.*

**OIL SEAL**


**TAPE**

Press the oil seal into the shock absorber with a hydraulic press until the oil seal driver stops at the edge of the outer case.

**OIL SEAL DRIVER**  
 07965-MB00100

**ATTACHMENT**  
 07965-MC70100

**ATTACHMENT**  
 07965-MC70100

**ATTACHMENT RING**  
 07965-ME70100

**OIL SEAL**
**GUIDE BUSHING**





Install the back-up ring.


Install the stop ring, being certain that it is fully seated in the ring groove in the outer case.

**WARNING**

*Do not forget to install the stop ring; the shock can come apart without this ring.*



Install the boot.  
Install the boot clip with the edge facing down.



**INSTALLATION**

Apply paste grease (containing more than 45% of molybdenum) to the upper mounting bushings.


**NOTE**

Use paste grease (containing more than 45% of molybdenum) as follows:

- \*MOLYKOTE G-n PASTE manufactured by Dow Corning, U.S.A.
- \*Locol Paste manufactured by Sumico Lubricant, Japan.
- \*Other lubricants of equivalent quality.

Install the shock absorber in the frame and tighten the upper and lower mounting bolts.

**TORQUE: 40–50 N·m (4.0–5.0 kg·m,  
29–36 ft·lb)**



**LOWER MOUNTING BOLT**



## REAR WHEEL/SUSPENSION

Install the electric panel and crankcase breather separator.

### NOTE

Route the wires, hoses and tubes properly (pages 1-9 thru 12).

Install the left frame side cover and seat.

Adjust the air pressure (page 3-19).




### SHOCK ABSORBER LINKAGE

#### REMOVAL

Remove the left and right mufflers.

Remove the shock link by removing the shock absorber lower mounting bolt, shock link-to-shock arm bolt, swingarm pinch bolt, and shock link shaft.

Remove the shock arms from the frame.




### LINKAGE PIVOT INSPECTION

Check the linkage needle bearings (bushings for '83) and collars for wear or damage. Inspect the dust seals for damage. Replace parts as necessary.

### SHOCK LINKAGE INSTALLATION

'83: Apply paste grease (containing more than 40% molybdenum) to the bushings and dust seals. See note on page 15-11.

After '83: Apply molybdenum disulfide grease to the needle bearings and dust seals.





Install the shock arms and shock link and tighten each bolt in the order listed.

**TORQUE:**

**SHOCK ARM-TO-FRAME:**

40–50 N·m (4.0–5.0 kg-m, 29–36 ft-lb)

**SHOCK LINK-TO-SHOCK ABSORBER**

40–50 N·m (4.0–5.0 kg-m, 29–36 ft-lb)


**SHOCK LINK-TO-SHOCK ARM:**

40–50 N·m (4.0–5.0 kg-m, 29–36 ft-lb)

**SWING ARM PINCH BOLT:**

20–30 N·m (2.0–3.0 kg-m, 14–22 ft-lb)

Install the mufflers.




**SWINGARM**

**REMOVAL**


Remove the rear wheel (page 15-3).

Remove the right muffler.

Remove the shock link pinch bolt and shock link shaft.



Remove the left and right swingarm pivot bolts.






## REAR WHEEL/SUSPENSION

Remove the lock pin from the rear brake torque rod bolt and remove the torque rod bolt.


Remove the swingarm from the frame.



LOCK PIN

TORQUE ROD BOLT

Remove the drive chain slider from the swingarm.




DRIVE CHAIN SLIDER

## PIVOT BEARING REPLACEMENT

Remove the pivot collar from the swingarm's right pivot. Remove the dust seal.

Remove the snap ring and drive out the right pivot bearings.



DUST SEAL


PIVOT COLLAR

SNAP RING



Remove the dust seal from the swingarm's left pivot.  
Remove the left pivot needle bearing with the special tool.


NEEDLE BEARING REMOVER  
07931-MA7000 NOT AVAILABLE IN U.S.A.



Drive a new needle bearing into the swingarm left pivot.

**CAUTION**

*To prevent swingarm damage, support the swingarm as shown.*




ATTACHMENT, 32 x 35 mm 07746-0010100  
PILOT, 20 mm 07746-0040500

Drive new ball bearings into the swingarm right pivot.



ATTACHMENT, 37 x 40 mm 07746-0010200  
PILOT, 17 mm 07746-0040400


Install the snap ring in the right swingarm pivot.  
Install the oil seals both pivots.  
Install the pivot collar into the right pivot.



**INSTALLATION**

Install the drive chain slider.


Install the swingarm in the frame.



Make sure that the rear brake torque rod's flanged washer is installed in the swingarm pivot.  
Connect the rear brake torque rod to the swingarm and tighten the pivot bolt.

**TORQUE: 18–25 N·m (1.8–2.5 kg·m, 13–18 ft·lb)**

Secure the bolt with the lock pin.





Install the left and right pivot bolts.  
Tighten the right pivot bolt.

**TORQUE: 85–105 N·m (8.5–10.5 kg·m,  
61–76 ft·lb)**



Tighten the left pivot bolt.

**TORQUE: 85–105 N·m (8.5–10.5 kg·m,  
61–76 ft·lb)**





Connect the swingarm and shock link and install  
the shock link shaft and shock link pinch bolt.  
Tighten the shock link pinch bolt.

**TORQUE: 20–30 N·m (2.0–3.0 kg·m, 14–22 ft·lb)**

Install the right muffler.

Install the rear wheel (page 15–8).







SERVICE INFORMATION	16- 1
TROUBLESHOOTING	16- 2
BRAKE FLUID REPLACEMENT/AIR BLEEDING	16- 3
BRAKE PAD/DISC	16- 5
FRONT MASTER CYLINDER	16- 8
BRAKE CALIPERS	16-10
REAR MASTER CYLINDER	16-14

## SERVICE INFORMATION

### GENERAL

- The brake calipers can be removed without disconnecting the hydraulic system.
- Bleed the hydraulic system if it is disassembled or if the brake feels spongy.
- Do not allow foreign material to enter the system when filling the reservoir.
- Avoid spilling brake fluid on painted surfaces or instrument lenses, as severe damage can result.
- Always check brake operation before riding the motorcycle.

### SPECIFICATIONS

ITEM	STANDARD	SERVICE LIMIT
Front disc thickness	4.5–5.2 mm (0.177–0.205 in)	4.0 mm (0.157 in)
Front disc runout	–	0.30 mm (0.012 in)
Front master cylinder I.D.	15.870–15.913 mm (0.6248–0.6265 in)	15.925 mm (0.6270 in)
Front master piston O.D.	15.827–15.854 mm (0.6231–0.6242 in)	15.815 mm (0.6226 in)
Front caliper piston O.D.	31.948–31.998 mm (1.2578–1.2598 in)	31.940 mm (1.2575 in)
Front caliper cylinder I.D.	32.030–32.080 mm (1.2610–1.2630 in)	32.090 mm (1.2634 in)
Rear master cylinder I.D.	14.000–14.043 mm (0.5512–0.5529 in)	14.055 mm (0.5533 in)
Rear master piston O.D.	13.957–13.984 mm (0.5495–0.5506 in)	13.945 mm (0.5490 in)
Rear caliper cylinder I.D.	27.000–27.050 mm (1.0630–1.0650 in)	27.060 mm (1.0654 in)
Rear caliper piston O.D.	26.918–26.968 mm (1.0598–1.0617 in)	26.910 mm (1.0594 in)
Rear disc thickness	6.5–7.2 mm (0.256–0.283 in)	6.0 mm (0.236 in)
Rear disc runout	–	0.30 mm (0.012 in)

**16**

### TORQUE VALUES

Front brake caliper bracket mount bolt (Right)	30–40 N·m (3.0–4.0 kg-m, 22–29 ft-lb)
Front brake caliper bracket mount bolt (Left-upper)	30–40 N·m (3.0–4.0 kg-m, 22–29 ft-lb)
(Left-lower)	20–25 N·m (2.0–2.5 kg-m, 14–18 ft-lb)
Brake caliper mount bolt	20–25 N·m (2.0–2.5 kg-m, 14–18 ft-lb)
Brake caliper pivot bolt	25–30 N·m (2.5–3.0 kg-m, 18–22 ft-lb)
Brake hose oil bolt	25–40 N·m (2.5–4.0 kg-m, 18–29 ft-lb)
Rear brake actuating arm	10–15 N·m (1.0–1.5 kg-m, 7–11 ft-lb)



## TOOL

### Special

Snap ring pliers

07914-3230001 or equivalent in U.S.A.

## TROUBLESHOOTING

### Brake lever/pedal soft or spongy

1. Air bubbles in hydraulic system
2. Low fluid level
3. Hydraulic system leaking

### Brake lever/pedal too hard

1. Sticking piston(s)
2. Clogged hydraulic system
3. Pads glazed or worn excessively

### Brake drag

1. Hydraulic system sticking
2. Sticking piston(s)

### Brakes grab

1. Pads contaminated
2. Disc or wheel misaligned

### Brake chatter or squeal

1. Pads contaminated
2. Excessive disc runout
3. Caliper installed incorrectly
4. Disc or wheel misaligned



## BRAKE FLUID REPLACEMENT/ AIR BLEEDING

Check the fluid level with the fluid reservoir parallel to the ground.

### CAUTION


- *Install the cover on the reservoir whenever operating the brake lever or pedal. Failure to do so will allow brake fluid to squirt out of the reservoir during brake operation.*
- *Avoid spilling fluid on painted surfaces. Place clean shop towels over the fuel tank whenever the system is being serviced.*

FRONT UPPER LEVEL



LOWER LEVEL

REAR UPPER LEVEL



LOWER LEVEL

## BRAKE FLUID DRAINING

Connect a bleed hose to the bleed valve to avoid spilling fluid.

### WARNING

*A brake fluid contaminated brake disc or pad reduces stopping power. Discard pads and clean a contaminated disc with a high quality brake degreasing agent.*

Loosen the caliper bleed valve and pump the brake lever or pedal.

Stop operating the lever or pedal when fluid stops flowing out of the bleed valve.

FRONT



REAR



## BRAKE FLUID FILLING

### NOTE

Do not mix different types of fluid since they may not be compatible.

Close the bleed valve, fill the reservoir, and install the cover.

To prevent piston overtravel and brake fluid seepage, keep a 20 mm (3/4 in) spacer between the handlebar grip and lever when bleeding the front brake system. When bleeding the rear brake system depress the pedal only as far as its normal travel. Pump up the system pressure with the lever or pedal until there are no air bubbles in the fluid flowing out of the reservoir small hole and lever or pedal resistance is felt.





## AIR BLEEDING

### NOTE

- Check the fluid level often while bleeding the brakes to prevent air from being pumped into the system.
- When using the Mityvac Brake Bleeder, follow the manufacturer's instructions.

### CAUTION

- Use only DOT4 brake fluid from a sealed container.
- Do not mix brake fluid types and never reuse the contaminated fluid which has been pumped out during brake bleeding, because this will impair the efficiency of the brake system.

Pump the brake lever or pedal to bring the caliper pads in contact with the disc.

Remove the master cylinder cap and fill the reservoir to near full.

Connect the Mityvac Brake Bleeder or equivalent to the bleeder valve.

Pump the brake bleeder and loosen the bleeder valve. Add fluid when the fluid level in the master cylinder reservoir is low.

Repeat above procedures until air bubbles do not appear in the plastic hose.

### NOTE

If air is entering the bleeder from around the bleeder valve threads, seal the threads with teflon tape.

If a Mityvac Brake Bleeder or equivalent not available, bleed the system as follows:

- 1) Connect a bleeder tube to the bleeder valve.
- 2) Squeeze the brake lever or depress the brake pedal, open the bleed valve 1/2 turn and then close the valve.

### NOTE

Do not release the brake lever or pedal until the bleed valve has been closed.

- 3) Release the brake lever or pedal slowly and wait several seconds after it reaches the end of its travel.

Repeat steps 1 and 2 until bubbles cease to appear in the fluid at the end of the hose.

Fill the fluid reservoir to the upper level mark.

### WARNING

A brake fluid contaminated brake disc or pad reduces stopping power. Discard contaminated pads and clean a contaminated disc with a high quality brake degreasing agent.

MITYVAC BRAKE BLEEDER  
 #6860-Commercially Available in U.S.A.

FRONT



RUBBER HOSE BLEEDER VALVE


MITYVAC BRAKE BLEEDER  
 #6860-Commercially Available in U.S.A.

REAR



BLEEDER VALVE RUBBER HOSE

FRONT



REAR





## **BRAKE PAD/DISC**

### **FRONT PAD REPLACEMENT**

#### **NOTE**


Always replace the brake pads in pairs to assure even disc pressure.

Remove the pad pin retainer bolt.


Right caliper: Remove the caliper bolt and pivot bolt.

Left caliper: Remove the caliper pivot bolt and anti-dive link bolt.


Remove the caliper from the bracket.




Remove the pad pin retainer and pull the pad pins out of the caliper.  
Remove the brake pads.



Position the pad spring in the caliper as shown.  
Push the caliper pistons in all the way.




Install the new pads in the caliper.  
Install the pad pins, one pad pin first, then install the other pin by pushing the pads against the caliper to depress the pad spring.



Place the pad pin retainer over the pad pins. Push the retainer down to secure the pins.



Install the pad pin retainer bolt.  
Install the caliper to the bracket so the disc is positioned between the pads, being careful not to damage the pads.  
Right caliper: Tighten the caliper bolt and pivot bolt.  
Left caliper: Tighten the caliper pivot bolt and anti-dive link bolt.






### REAR BRAKE PAD REPLACEMENT

Loosen the caliper bolt and remove it from the caliper bracket.

Pivot the caliper up out of the way.

Replace the rear brake pads using the same method as used for front brake pad replacement.



CALIPER BOLT

### DISC THICKNESS

Measure the thickness of each disc.

**SERVICE LIMIT:**

**FRONT:** 4.0 mm (0.16 in)


**REAR:** 6.0 mm (0.24 in)



### BRAKE DISC WARPAGE

Measure brake disc for warpage.

**SERVICE LIMIT:** 0.30 mm (0.012 in)



## FRONT MASTER CYLINDER

### DISASSEMBLY


Drain brake fluid from the hydraulic system. Remove the brake lever and rear view mirror from the master cylinder. Disconnect the brake hose.

#### CAUTION

*Avoid spilling brake fluid on painted surfaces. Place a rag over the fuel tank whenever the brake system is being serviced.*

#### NOTE

When removing the fluid hose bolt, cover the end of the hose to prevent contamination. Secure the hose to prevent fluid from leaking out.



Disconnect the front brake switch wires. Remove the front brake master cylinder.

Remove the piston boot and the snap ring from the master cylinder body.




SNAP RING PLIERS or EQUIVALENT IN U.S.A.  
07914-3230001

Remove the secondary cup and piston. Then remove the primary cup and spring.

Remove the brake light switch from the master cylinder body, if necessary.

Clean the inside of the master cylinder and reservoir with brake fluid.






**INSPECTION**

Measure the master cylinder I.D.  
Check the master cylinder for scores, scratches or nicks.

**SERVICE LIMIT: 15.925 mm (0.6270 in)**



Measure the master piston O.D.

**SERVICE LIMIT: 15.815 mm (0.6226 in)**

Check the primary and secondary cups for damage before assembly.



**ASSEMBLY**

**CAUTION**

*Keep the master cylinder piston, cylinder and spring as a set; don't substitute individual parts.*


Assemble the master cylinder. Coat all parts with clean brake fluid before assembly. Install the spring and primary cup together.

Dip the piston cup in brake fluid before assembly.


**CAUTION**

*When installing the cups, do not allow the lips to turn inside out and be certain the snap ring is firmly seated in the groove.*

Install the piston and snap ring.  
Install the boot.



Place the front master cylinder on the handlebar and install its clamp and two mounting bolts. Align the index mark on the clamp with the punch mark on the handlebar. Tighten the upper bolt first, then tighten the lower bolt.  
 Install the fluid hose with the bolt and two sealing washers.  
 Install the brake lever.  
 Install the rear view mirror.  
 Connect the front brake switch wires.  
 Fill the reservoir to the upper level and bleed the brake system according to page 16-4.



## BRAKE CALIPERS


### FRONT BRAKE CALIPER REMOVAL

Place a clean container under the caliper and disconnect the brake hose from the caliper.

**CAUTION**

*Avoid spilling brake fluid on painted surfaces.*

Right caliper: Remove the caliper pivot bolt and caliper bolt, and remove the caliper.  
 Left caliper: Remove the caliper pivot bolt and anti-dive link bolt, and remove the caliper.




### REAR BRAKE CALIPER REMOVAL

Place a clean container under the caliper and disconnect the brake hose from the caliper.

**CAUTION**

*Avoid spilling brake fluid on the painted surfaces to prevent paint damage.*


Remove the caliper pivot bolt and caliper bolt, and remove the rear brake caliper.





### DISASSEMBLY

- Remove the brake pads (page 16-5).
- Remove the pad spring.
- Remove the caliper pivot collar and boots.
- Remove the pistons from the caliper.



If necessary, apply compressed air to the caliper fluid inlet to get the piston out. Place a shop rag under the caliper to cushion the piston when it is forced out. Use the air in short spurts.

**WARNING**

*Do not bring the nozzle too close to the inlet.*

Examine the pistons and cylinders for scoring, scratches or other damage and replace if necessary.



Push the piston seals in and lift them out, then discard them.  
Clean the piston seal grooves with brake fluid.

**CAUTION**

*Be careful not to damage the piston sliding surfaces.*





**PISTON INSPECTION**

Check the pistons for scoring, scratches or other damage. Measure the piston diameter with a micrometer.

**SERVICE LIMIT:**

**FRONT:** 31.940 mm (1.2575 in)

**REAR:** 26.910 mm (1.0594 in)




**CYLINDER INSPECTION**

Check the caliper cylinder for scoring, scratches or other damage. Measure the caliper cylinder bore.

**SERVICE LIMIT:**

**FRONT:** 32.090 mm (1.2634 in)

**REAR:** 27.060 mm (1.0654 in)



**ASSEMBLY**

If the collar boots are hardened or deteriorated, replace them with new ones.

The piston seals must be replaced with new ones whenever they are removed. Coat the seals with silicone grease or brake fluid before assembly.


Install the pistons with the dished ends toward the pads.

Apply medium grade of Hi-Temperature silicon grease to the collar and inside of the collar grease.

Install the collar boots and collar making sure that the boots are seated in the collar and caliper grooves properly.

Install the pad spring.

Install the pads (page 16-5).






**FRONT BRAKE CALIPER  
INSTALLATION**

Make sure that the retainer clip is in position on the caliper bracket.

Inspect the condition of the caliper pivot boot.

Apply silicone grease to the caliper pivot bolt.



RETAINER CLIP

Install the caliper assembly over the brake disc so that the disc is positioned between the pads.

**CAUTION**

*Be careful not to damage the pads.*

Right caliper: Install the caliper pivot bolt and caliper bolt, and tighten them securely.


Left caliper: Install the caliper pivot bolt and anti-dive link bolt, and tighten them securely.

Connect the brake hose to the caliper with the bolt and two sealing washers.

Fill the brake fluid reservoir and bleed the brake system (page 16-4).

RIGHT CALIPER

LEFT CALIPER




**REAR BRAKE CALIPER INSTALLATION**

Make sure that the retainer clip is in position on the caliper bracket.

Inspect the condition of the caliper pivot boot.

Apply silicone grease to the caliper pivot bolt.



RETAINER CLIP


Install the caliper assembly over the brake disc so that the disc is positioned between the pads, being careful not to damage the pads.  
Install the caliper pivot bolt and caliper bolt and tighten them securely.  
Connect the brake hose to the caliper with the bolt and two sealing washers.  
Fill the rear brake fluid reservoir and bleed the rear brake system (page 16-4).



## REAR MASTER CYLINDER

### REMOVAL

Drain the rear brake hydraulic system (page 16-3).  
Remove the brake hose bolt and disconnect the brake hose.



Loosen the rear master cylinder mount bolts.  
Remove the right footpeg bracket.


Unhook the rear brake switch spring from the rear brake actuating arm.





Remove the hose connector screw and disconnect the master cylinder hose.

MASTER CYLINDER HOSE




HOSE CONNECTOR

Unhook the rear brake pedal return spring. Remove the rear brake actuating arm bolt and the middle arm.

Remove the cotter pin, washer and joint pin, and disconnect the brake actuating arm from the master cylinder push rod.

ACTUATING ARM BOLT

RETURN SPRING




COTTER PIN

JOINT PIN

WASHER

Remove the rear master cylinder from the footpeg bracket.



REAR BRAKE MASTER CYLINDER

**DISASSEMBLY**


Remove the rubber boot.

Remove the snap ring and push rod from the master cylinder body.

Remove the master piston, primary cup and spring.

It may be necessary to apply a small amount of air pressure to the fluid outlet to remove the master piston and primary cup.

Clean all parts with brake fluid.



SNAP RING PLIERS or EQUIVALENT IN U.S.A.  
07914-323001

**CYLINDER I.D. INSPECTION**

Measure the inside diameter of the master cylinder bore.

**SERVICE LIMIT: 14.055 mm (0.5533 in)**

Check for scores, scratches or nicks.



**PISTON O.D. INSPECTION**

Measure the master piston O.D.

**SERVICE LIMIT: 13.945 mm (0.5490 in)**

Check the primary cup and piston cup for damage.





**ASSEMBLY**

**CAUTION**

*Keep the master cylinder piston, cylinder and spring as a set; do not substitute individual parts.*

Assemble the master cylinder.  
Coat all parts with clean brake fluid.

Dip the piston cup in brake fluid before assembly.

**CAUTION**

*When installing the cups, do not allow the lips to turn inside out and be certain the snap ring is seated firmly in the groove.*



Install the primary cup and piston.

Install the push rod and snap ring.

Install the rubber cover.

**INSTALLATION**

Install the master cylinder to the right footpeg bracket.



**MASTER CYLINDER**


Connect the rear brake actuating arm to the master cylinder push rod with the joint pin, and secure the joint pin with the washer and a new cotter pin.

Install the actuating arm onto the rear brake pedal shaft, aligning the punch marks on the arm and shaft.

Hook the rear brake pedal return spring to the actuating arm.

Tighten the actuating arm bolt.

**TORQUE: 10–15 N·m (1.0–1.5 kg·m, 7–11 ft·lb)**



**JOINT PIN**


Connect the master cylinder hose to the master cylinder with a new O-ring and screw.

Hook the rear brake switch spring to the actuating arm.

MASTER CYLINDER HOSE




REAR BRAKE SWITCH SPRING



ACTUATING ARM

Install the right footpeg bracket.  
Tighten the bracket bolt.  
Tighten the rear brake master cylinder mount bolts.

RIGHT FOOTPEG BRACKET



MASTER CYLINDER MOUNT BOLTS

Connect the rear brake hose with the fluid bolt and two sealing washers.  
Fill and bleed the rear brake system (page 16-4).

FLUID BOLT







MEMO







BATTERY/CHARGING SYSTEM





SERVICE INFORMATION	17-1
TROUBLESHOOTING	17-2
BATTERY	17-3
CHARGING SYSTEM	17-4

## SERVICE INFORMATION

### GENERAL

- Battery fluid level should be checked regularly. Fill with distilled water when necessary.
- Quick charge a battery only in an emergency; slow-charging is preferred.
- Remove the battery from the motorcycle for charging. If the battery must be charged on the motorcycle, disconnect the battery cables.

**WARNING**

*Do not smoke or allow flames near a charging battery. The gas produced by a battery will explode if flames or sparks are brought near.*

- All charging system components can be tested on the motorcycle.
- Alternator removal is in Section 9.

### SPECIFICATIONS

Battery	Capacity	12V 14AH
	Specific gravity	1.280/20°C (68°F)
	Charging rate	1.4 amperes maximum
Voltage regulator	Type	Transistorized non-adjustable regulator
	Regurate voltage	14.0 V-15.0 V

**TROUBLESHOOTING****No power – key turned on:**

1. Dead battery
  - Low fluid level
  - Low specific gravity
  - Charging system failure
2. Disconnected battery cable
3. Main fuse burned out
4. Faulty ignition switch

**Low power – key turned on:**

1. Weak battery
  - Low fluid level
  - Low specific gravity
  - Charging system failure
2. Loose battery connection

**Low power – engine running:**

1. Battery undercharged
  - Low fluid level
  - One or more dead cells
2. Charging system failure

**Intermittent power:**

1. Loose battery connection
2. Loose charging system connection
3. Loose starting system connection
4. Loose connection or short circuit in ignition system
5. Loose connection or short circuit in lighting system

**Charging system failure:**

1. Loose, broken or shorted wire or connection
2. Faulty voltage regulator/rectifier
3. Faulty alternator



## BATTERY

### REMOVAL

Remove the battery holder bolt, then swing the holder out of the way.  
Disconnect the negative cable at the battery, then disconnect the positive cable.  
Disconnect the battery breather hose from the battery.  
Remove the battery.

### TESTING SPECIFIC GRAVITY

Test each cell with a hydrometer.

**SPECIFIC GRAVITY: 1.270–1.290 (20°C, 68°F)**

1.270–1.290	Fully charged
Below 1.260	Undercharged

### NOTES

- The battery must be recharged if the specific gravity is below 1.230.
- The specific gravity varies with the temperature as shown in the accompanying table.
- Replace the battery if sulfation is evident or if the space below the cell plates is filled with sediment.

### WARNING

*The battery contains sulfuric acid. Avoid contact with skin, eyes, or clothing.  
Antidote: Flush with water and get prompt medical attention.*

### CHARGING

Remove the battery cell caps.  
Fill the battery cells with distilled water to the upper level line, if necessary.  
Connect the charger positive (+) cable to the battery positive (+) terminal.  
Connect the charger negative (–) cable to the battery negative (–) terminal.

**Charging current: 1.4 amperes max.**


Charge the battery until specific gravity is 1.270–1.290 at 20°C (68°F).

### WARNING


- Before charging a battery, remove the cap from each cell.
- Keep flames and sparks away from a charging battery.
- Turn power ON/OFF at the charger, not at the battery terminals to prevent sparks.
- Discontinue charging if the electrolyte temperature exceeds 45°C (113°F).



**BATTERY HOLDER**



Specific gravity changes by 0.007 for every 10°C.





## BATTERY/CHARGING SYSTEM

### CAUTION

- *Quick-charging should only be done in an emergency; slow-charging is preferred.*
- *Route the breather tube as shown on the battery caution label.*

After installing the battery, coat the terminals with clean grease.

## CHARGING SYSTEM

Warm the engine and warm it up to operating temperature.

Remove the frame right side cover and seat.

Connect the voltmeter between the battery terminals as shown.

Start the engine and allow it idle.

Check the voltage by raising the engine speed gradually. The voltage should be maintained within the regulate voltage.



### REGULATE VOLTAGE: 14.0–15.0 V

If voltage exceeds 15 V when raising the engine speed, the likelihood is:

- Open or short circuit (black wire of the regulator/rectifier)
- Loose or poorly contacted regulator/rectifier coupler
- Faulty regulator/rectifier

If the voltage does not increase from the battery voltage when raising the engine speed, the likelihood is:

- Open or short circuit between the alternator and regulator/rectifier
- Loose or poorly contacted alternator or regulator/rectifier couplers
- Open circuit in wire harness (red/white or green wires)
- Faulty alternator or regulator/rectifier





### STATOR CONTINUITY TEST

Remove the left side cover.  
 Disconnect the alternator and regulator/rectifier coupler.  
 Check for continuity between the leads, and between the leads and ground.  
 Replace the stator if there is no continuity between the leads, or if there is continuity between the leads and ground.




### VOLTAGE REGULATOR/RECTIFIER TEST

Remove the left side cover.  
 Disconnect the regulator/rectifier couplers.  
 Check for continuity between the leads with an ohmmeter.

#### NOTE

The test results shown are for a positive ground ohmmeter and the opposite results will be obtained when a negative ground ohmmeter is used.




#### NORMAL DIRECTION: CONTINUITY

	⊕ probe	⊖ probe
I	YELLOW	GREEN
II	RED/WHITE	YELLOW

#### REVERSE DIRECTION: NO CONTINUITY

	⊕ probe	⊖ probe
I	GREEN	YELLOW
II	YELLOW	RED/WHITE






**BATTERY/CHARGING SYSTEM**

**VOLTAGE REGULATOR  
PERFORMANCE TEST**

Connect a voltmeter across the battery.  
Check regulator performance with the engine running. The regulator must divert current to ground when battery voltage reaches 14.0 ~ 15.0 V.







MEMO



**IGNITION SYSTEM**



IGNITION SYSTEM DIAGRAM





SERVICE INFORMATION	18-1
TROUBLESHOOTING	18-2
IGNITION COIL	18-3
TRANSISTORIZED IGNITION SYSTEM	18-4
IGNITION TIMING	18-5

## SERVICE INFORMATION

### GENERAL

- A TRANSISTORIZED IGNITION SYSTEM is used and no adjustments can be made.

### SPECIFICATIONS

		ND	NGK
Spark plug	Standard	X24EPR-U9	DPR8EA-9
	For cold climate Below 5°C (41°F)	X22EPR-U9	DPR7EA-9
	For extended high speed driving	X27EPR-U9	DPR9EA-9
Spark plug gap	0.8–0.9 mm (0.031–0.035 in)		
Ignition timing	At idle – VF750F: 10°, VF700F: 15° BTDC		
	Full advance 37° BTDC/3,300 rpm		
Pulse generator air gap	0.3–0.9 mm (0.012–0.035 in)		

### TOOL

#### Special

Timing inspection cover 07998-MB00000



## IGNITION SYSTEM

---

### TROUBLESHOOTING

The ignition system has two sub-systems; one for the No. 1 and No. 3 cylinders and one for the No. 2 and No. 4 cylinders. Determine which sub-system is faulty, then proceed to the detailed tests below.

#### **Engine cranks but will not start**

- Engine stop switch OFF
- No spark at plugs
- Faulty transistorized spark unit
- Faulty pulse generator

#### **No spark at plug**

- Engine stop switch OFF
- Poorly connected, broken or shorted wires
  - Between ignition switch and engine stop switch
  - Between spark unit and engine stop switch
  - Between spark unit and ignition coil
  - Between ignition coil and plug
  - Between spark unit and pulse generator
- Faulty ignition coil
- Faulty ignition switch
- Faulty spark unit
- Faulty pulse generator

#### **Engine starts but runs poorly**

- Ignition primary circuit
  - Faulty ignition coil
  - Loose or bare wire
  - Intermittent short circuit
- Secondary circuit
  - Faulty plug
  - Faulty high tension wire

#### **Timing advance incorrect**


- Faulty pulse generator
- Faulty spark unit



## IGNITION COIL

Remove the seat and fuel tank.

IGNITION COILS




## CONTINUITY TEST

Disconnect the coils primary leads.

Measure the primary coil resistance.

RESISTANCE:  $2.8 \Omega$

IGNITION COIL TERMINALS



Measure the secondary coil resistance with the spark plug caps in place.


RESISTANCE:  $21-28 \text{ k} \Omega$



## IGNITION SYSTEM

Remove the spark plug cap resistors and measure the secondary coil resistance (page 18-3).

**RESISTANCE 13.6–15.5 k $\Omega$**



## TRANSISTORIZED IGNITION SYSTEM

### PULSE GENERATOR TEST

Remove the right side cover.  
 Disconnect the pulse generator coupler and measure the coil resistance.

**RESISTANCE: Approximately 480  $\Omega$**

Between white/yellow and yellow leads (1, 3 cylinders)

Between white/blue and blue leads (2, 4 cylinders)




### PULSE GENERATOR REPLACEMENT

Remove the clutch cover (page 7-10).  
 Remove the pulse generator mounting bolts, and pulse generators.

Install new pulse generators.  
 Measure the air gap between the pulse generator and rotor.

**AIR GAP: 0.3–0.9 mm (0.012–0.035 in)**

Install the clutch cover (page 7-22).  
 Recheck the ignition timing (page 18-5).





### SPARK UNIT

If the pulse generators, ignition coils and wiring are good, and the ignition timing is not within specification; replace the spark units with new ones and recheck the ignition timing.

1, 3 CYLINDER  
SPARK UNIT

2, 4 CYLINDER  
SPARK UNIT



### IGNITION TIMING

Warm up the engine and remove the alternator cover. Align the F mark on the flywheel with the rear crankcase mating surface.

Use a felt pen to mark a dark line and "1-3F" in line with the F mark on the end surface of the flywheel.

Install the timing inspection cover.  
Connect the timing light to the high tension wire of the No. 1 or No. 3 cylinder.  
Start the engine and check the ignition timing.

**AT IDLE SPEED:** The dark line (1-3F) should align with the index mark on the timing cover.

**1,300–1,750 rpm:** The advance starts.


**3,100–3,500 rpm:** The advance ends and the index mark should be between the full advance marks.

Connect the timing light to the high tension wire of the No. 2 or No. 4 cylinder and check the ignition timing for No. 2 and No. 4 cylinders.


#### NOTE



The ignition system is transistorized and cannot be adjusted. If the ignition timing is incorrect, check the spark units and pulse generators.  
Replace parts as required.

After timing inspection, check the engine oil level and add if necessary.



TIMING INSPECTION COVER  
07998-MB00000







SERVICE INFORMATION	19-1
TROUBLESHOOTING	19-1
STARTER MOTOR	19-2
STARTER RELAY SWITCH	19-5
CLUTCH DIODE	19-5

## SERVICE INFORMATION

### GENERAL

- The starter motor can be removed with the engine in the frame.

### SPECIFICATIONS

		STANDARD	SERVICE LIMIT
Starter motor	Brush spring tension	680–920 g (24.0–32.5 oz)	545 g (19.2 oz)
	Brush length	12.0–13.0 mm (0.47–0.51 in)	6.5 mm (0.26 in)

## TROUBLESHOOTING

### Starter motor will not turn:

1. Battery discharged.
2. Faulty ignition switch.
3. Faulty starter switch.
4. Faulty neutral switch.
5. Faulty starter relay switch.
6. Loose or disconnected wire or cable.
7. Clutch diode open.

### Starter motor turns engine slowly

1. Low specific gravity in battery.
2. Excessive resistance in circuit.
3. Binding in starter motor.

### Starter motor turns, but engine does not turn:

1. Faulty starter clutch.
2. Faulty starter motor gears.
3. Faulty starter motor or idle gear.

### Starter motor and engine turns, but engine does not start

1. Faulty ignition system.
2. Engine problems.
  - Low compression.
  - Fouled spark plugs.



## STARTER MOTOR



### REMOVAL

**WARNING**

With the ignition switch OFF, remove the negative cable at the battery before servicing the starter motor.

Remove the lower radiator (page 6-7).

Disconnect the starter motor cable at the motor.  
Remove the starter motor mounting bolts, and starter motor.






### BRUSH INSPECTION

Remove the starter motor case screws.  
Inspect the brushes and measure the brush length.  
Measure brush spring tension with a spring scale.

#### SERVICE LIMITS:

Brush length: 6.5 mm (0.26 in)  
Brush spring tension: 545 g (19.2 oz)

BRUSH SPRING  
BRUSH LENGTH



### COMMUTATOR INSPECTION

Remove the starter motor case.

#### NOTE

Record the location and number of shims.

Inspect the commutator bars for discoloration.  
Bars discolored in pairs indicate grounded armature coils.

#### NOTE

Do not use emery or sand paper on the commutator.

COMMUTATOR



### CONTINUITY BETWEEN COMMUTATOR BAR PAIRS: NORMAL

Check for continuity between pairs of commutator bars.  
There should be continuity.  
Also, make a continuity check between individual commutator bars and the armature shaft.  
There should be no continuity.



### NO CONTINUITY BETWEEN COMMUTATOR BARS AND ARMATURE SHAFT: NORMAL

## ELECTRIC STARTER

### FIELD COIL INSPECTION

Check for continuity from the cable terminal to the motor case.


There should be no continuity.

Then check for continuity from the cable terminal to the brush.

There should be continuity.

Replace the starter motor if the field coil does not have continuity or if it is shorted to the motor case.

NO CONTINUITY BETWEEN  
CABLE TERMINAL AND MOTOR CASE: NORMAL




CONTINUITY BETWEEN  
CABLE TERMINAL AND BRUSH WIRE (INSULATED): NORMAL

### ASSEMBLY/INSTALLATION

Assemble the starter motor.

Align the case notch with the brush holder pin.


BRUSH HOLDER    NOTCH    PIN



Install the rear cover aligning its slot with the brush holder pin.

Install the starter motor in the reverse order of removal.

PIN    SLOT



BRUSH HOLDER    REAR BRACKET




## STARTER RELAY SWITCH

### INSPECTION

Depress the starter switch button with the ignition ON.


The coil is normal if the starter relay switch clicks.



Connect an ohmmeter to the starter relay switch terminals.

Connect a 12 V battery to the switch cable terminals.

The switch is normal if there is continuity.




## CLUTCH DIODE

### REMOVAL

Remove the fuel tank.

Remove the clutch diode from the wire harness.




**ELECTRIC STARTER**

NORMAL DIRECTION: CONTINUITY  
REVERSE DIRECTION: NO CONTINUITY

**INSPECTION**

Check for continuity with an ohmmeter.





SERVICE INFORMATION	20-1	FUEL PUMP RELAY	20-6
OIL PRESSURE SWITCH	20-2	FUEL LEVEL SENSOR	20-7
BRAKE LIGHT SWITCH	20-2	THERMOSTATIC SWITCH	20-8
NEUTRAL SWITCH	20-3	FAN MOTOR RELAY	20-8
CLUTCH SWITCH	20-3	TEMPERATURE SENSOR	20-9
HANDLEBAR SWITCHES	20-4	TEMPERATURE GAUGE	20-10
IGNITION SWITCH	20-5	TACHOMETER	20-10
FUEL PUMP	20-6	BRAKE AND TAIL LIGHT SENSOR	20-10

## SERVICE INFORMATION

### GENERAL

- Some wires have different colored bands around them near the connector. These are connected to other wires which correspond with the band color.
- All plastic plugs have locking tabs that must be released before disconnecting, and must be aligned when reconnecting.
- The following color codes used are indicated throughout this section and on the wiring diagram.

Bu = Blue	G = Green	LG = Light Green	R = Red
Bl = Black	Gr = Grey	O = Orange	W = White
Br = Brown	LB = Light Blue	P = Pink	Y = Yellow

- To isolate an electrical failure, check the continuity of the electrical path through the part. A continuity check can usually be made without removing the part from the motorcycle. Simply disconnect the wires and connect a continuity tester or volt-ohmmeter to the terminals or connections.
- A continuity tester is useful when checking to find out whether or not there is an electrical connection between the two points. An ohmmeter is needed to measure the resistance of a circuit, such as when there is a specific coil resistance involved, or when checking for high resistance caused by corroded connections.

**SWITCHES**
**OIL PRESSURE SWITCH**

Disconnect the oil pressure switch lead and remove the switch.

Check for continuity while applying pressure to the switch.

**Continuity:** Below 20 kPa (0.2 kg/cm<sup>2</sup>, 2.8 psi)  
**No continuity:** Above 20–40 kPa (0.2–0.4 kg/cm<sup>2</sup>, 2.8–5.7 psi)

Replace the switch if necessary.


Apply a liquid sealant to the switch threads before installing the switch.

Screw the switch into the crankcase but stop two threads from the bottom. Then tighten it to the specified torque.

**TORQUE:** 15–20 N·m (1.5–2.0 kg·m, 11–14 ft·lb)

**NOTE**

To prevent crankcase damage, do not over-tighten the switch.



OIL PRESSURE SWITCH

REAR BRAKE LIGHT SWITCH WIRE


**BRAKE LIGHT SWITCH**

Check the rear brake light switch for continuity with the rear brake applied.

Check the front brake light switch for continuity with the front brake applied.

Replace the switches if necessary.

FRONT BRAKE LIGHT SWITCH





## NEUTRAL SWITCH

Remove the left side cover and disconnect the neutral switch connector.

Check the switch for continuity between the switch connector terminal and ground.

There should be continuity with the transmission in neutral and no continuity with the transmission in any gear.

NEUTRAL SWITCH CONNECTOR



## REMOVAL

Remove the neutral switch cover.

Remove the neutral switch attaching screws and the switch.


## INSTALLATION

Install the neutral switch in the reverse order of removal. Tighten the switch mounting screws.

**TORQUE: 7–11 N·m**  
**(0.7–1.1 kg·m, 5–8 ft·lb)**

Install the neutral switch cover.

SCREWS



NEUTRAL SWITCH COVER

NEUTRAL SWITCH COVER

## CLUTCH SWITCH

Check continuity of the clutch lever (safety) switch with the clutch released and applied. Replace if necessary.

CLUTCH SWITCH



CLUTCH APPLIED: CONTINUITY  
CLUTCH RELEASED: NO CONTINUITY





**SWITCHES**


**HANDLEBAR SWITCHES**

The handlebar cluster switches (lights, turn signals, horn, etc.) must be replaced as assemblies.

Remove the fairing, headlight, and headlight bracket.

Continuity tests for the components of the handlebar cluster switches follow:

Continuity should exist between the color coded wires in each chart.



**HEADLIGHT HI-LOW SWITCH**

HI: Bu/W to Bu  
MIDDLE (N): Bu/W to W to Bu  
LO: Bu/W to W

Headlight Hi-Low Switch

	HL2	Hi	Lo
Hi	○	○	
(N)	○	○	○
Lo	○		○
Color code	Bu/W	Bu	W

**TURN SIGNAL SWITCH**

LEFT: Gr to O, Br/W to LB/W  
OFF: Br/W to LB/W and O/W  
RIGHT: Gr to LB, Br/W to O/W

Turn Signal Switch

	W	L	R	P1	PR	PL
LEFT	○	○		○	○	
OFF				○	○	○
RIGHT	○		○	○		○
Color code	Gr	O	LB	Br/W	LB/W	O/W

**HORN BUTTON**

LG to W/G with button depressed  
No continuity with button released

Horn Button

	Ho	BAT3
Color code	LG	W/G



**STARTER BUTTON**

BI to Y/R with button pushed in.  
BI/R to Bu/W with button out.

Starter Button


	IG	ST	HL1	HL2
OUT			○ — ○	
START	○ — ○			
Color code	BI	Y/R	BI/R	Bu/W

**ENGINE STOP SWITCH**

RUN: BI to BI/W  
OFF: No continuity

Engine Stop Switch

	BAT <sub>2</sub>	IG
OFF		
RUN	○ — ○	
Color code	BI/W	BI



**IGNITION SWITCH**


Remove the fairing and headlight. Disconnect the ignition switch coupler.

Check continuity of terminals on the ignition switch coupler in each switch position.

**SWITCH POSITION**

LOCK: No continuity  
OFF: No continuity  
ON: R to BI, Br/W to Br — continuity  
PARK: Br to R — continuity

Terminal Position	PA	BAT <sub>1</sub>	IG	TL <sub>1</sub>	TL <sub>2</sub>
P	○ — ○				
ON		○ — ○		○ — ○	
OFF					
LOCK					
Color code	Br	R	BI	Br/W	Br



## SWITCHES

### IGNITION SWITCH DISASSEMBLY

Insert the key and turn it so it is part way between the "ON" and "OFF" detent positions.

Pry open the wire retainer.

Push in the lugs, that are locked in the slots then pull the contact base from the switch.

Assemble in the reverse order of removal.

### FUEL PUMP

Remove the frame side covers, seat and fuel tank.

Turn the fuel valve and ignition switch off.

Disconnect the fuel pump relay coupler and short the white and black wire terminals with a jumper wire.

Disconnect the fuel line at the fuel line joint and hold a graduated beaker under the outlet tube.

Reinstall the fuel tank.

#### WARNING

- Do not allow flames or sparks near gasoline.
- Wipe up spilled gasoline at once.

Turn the ignition switch on and let fuel flow into the beaker for 5 seconds, then turn the ignition switch off. Multiply the amount in the beaker by 12 to determine the fuel pump flow capacity per minute.

#### FUEL PUMP FLOW CAPACITY:

660cc (22 US oz, 18.6 Imp oz)  $\pm$  10%/minute

#### NOTE

- Use a fully charged battery or false readings may result.
- Battery voltage should be above 12.5 V.

If the fuel pump flow capacity is below the specification, measure the voltage at the fuel pump coupler. Replace the fuel pump if battery voltage is present.

### FUEL PUMP RELAY

Check for a burnt sub-fuse.




Check the relay coupler for improper contact and looseness.

Measure the voltage between the relay black wire and a body ground. The battery voltage should register with the ignition switch ON.

Make sure that the fuel pump operates while the relay coupler black and white wires are shorted and the ignition switch is ON.

If the pump does not operate, check the fuel pump coupler for improper contact and the fuel pump.

Check for continuity between the ignition control unit blue wire and the fuel pump relay coupler blue wire. If there is continuity, replace the fuel pump relay. If there is no continuity, replace the wire harness.






## FUEL LEVEL SENSOR

### REMOVAL


Remove the fuel tank and drain the fuel.  
Remove the fuel level sensor attaching nuts and fuel level sensor.




### INSPECTION

Measure the resistance of the fuel level sensor in the full and empty float positions.

**RESISTANCE: FULL 3.5–9.5  $\Omega$**   
**EMPTY 90–100  $\Omega$**



Turn the ignition switch ON.  
Connect the fuel level sensor coupler to the wire harness. Move the float to full and empty and check the fuel gauge needle in both positions. If the fuel gauge does not indicate the proper level, replace it with a new one.





## THERMOSTAT SWITCH

The cooling fan motor is actuated by the thermostatic switch located in the lower radiator.


If the fan motor does not start, disconnect the black and green leads from the thermostatic switch and short them together with a jumper wire as shown. Turn the ignition switch on.

The cooling fan motor should start running.

If it does not start, check for battery voltage from the black lead (positive) to black/blue (negative) of the fan motor coupler.

If there is no voltage, check for a blown or faulty fuse, loose terminals or connectors, or an open circuit.

If it starts, inspect the fan thermostatic switch as follows:




Suspend the switch in a pan of coolant (50—50 mixture) and check the temperature at which the switch opens and closes. Make sure that there is no switch continuity with room temperature and gradually raise the coolant temperature. The switch should be continuity (close) at 98—102°C (208—215°F)

### NOTE

Maintain the high temperature for 3 minutes before testing continuity. A sudden change in temperature will cause an error in the reading.

Do not let the thermometer or switch touch the pan as it will give a false reading.

Soak the switch in coolant up to its threads.



## FAN MOTOR RELAY ('83 VF750F)

### NOTE

The VF700F/VF750F after '83 do not have the fan motor relay.

The '83 wiring diagram calls this part a Main Relay.


Remove the left side cover and disconnect the fan motor relay coupler.





Connect a fully charged 12 V battery and an ohmmeter to the relay terminals as shown.


The relay is normal if there is continuity when voltage is applied.



## TEMPERATURE SENSOR

Disconnect the green/blue wire from the temperature sensor.

Drain the coolant and remove the temperature sensor from the thermostat case.



Suspend the unit in oil over a burner and measure the resistance through the unit as the oil heats up.


Temperature	60°C	85°C	110°C	120°C
	140°F	185°F	230°F	248°F
Resistance	104.0Ω	43.9Ω	20.3Ω	16.1Ω

**WARNING**

*Wear gloves and eye protection.*

**NOTE**

- Oil must be used as the heated liquid to check operation above 100°C (212°F).
- You'll get false readings if either the thermometer or temperature sensor touches the pan.



## TEMPERATURE GAUGE


Disconnect the wire from the temperature sensor and short it to ground.

Turn the ignition switch to ON.

The temperature gauge needle should move all the way to the H.

### CAUTION


*Do not leave the temperature sensor wire grounded for longer than a few seconds or the temperature gauge will be damaged.*



## TACHOMETER

If the tachometer does not work properly, replace the 1-3 spark unit with a new one and recheck the operation.

If the problem still appears, replace the spark unit with the original one and tachometer with a new one.



## BRAKE AND TAIL LIGHT SENSOR


Turn the ignition switch on.

Check the source voltage at the black/brown lead. If there is no voltage, check and repair the source circuit.

If there is voltage, measure the voltage at the white/yellow (positive) and green/yellow (negative) wires.

**VOLTAGE: 5V**

If there is no voltage, replace the sensor unit.



'83

AFTER '83



V45 |

METER



12V32  
R FR

12V8

12V32  
L FR






**INTERCEPTOR (VF750F)**


- |    |        |    |             |
|----|--------|----|-------------|
| B  | BLACK  | B  | BROWN       |
| Y  | YELLOW | O  | ORANGE      |
| Bu | BLUE   | Lb | LIGHT BLUE  |
| G  | GREEN  | Lg | LIGHT GREEN |
| R  | RED    | P  | PINK        |
| W  | WHITE  | Gr | GRAY        |

**0030Z-MB2-9000**

# 21. WIRING DIAGRAMS



**21**


0030Z—MB2—6700




# HONDA VF700/750 INTERCEPTOR

'83

V45 INTERCEPTOR (VF750F)



SWITCH CONTINUITY





V-4 ENGINE FEATURES

22-1

ONE-WAY CLUTCH SYSTEM

22-2

## V-4 ENGINE FEATURES

The engine design is a DOHC, 16-valve, water cooled V-4.

The cylinders are arranged in two banks of two cylinders, 90 degrees apart.

The pent-roof combustion chamber has four valves per cylinder (two intake and two exhaust valves) ensure highly-efficient intake and exhaust flow.


- **One-way clutch**

Prevents rear wheel lock-up during rapid deceleration caused by down shifting of the transmission at high engine speed.

- **Self-adjusting hydraulic clutch**

Hydraulically assisted, the clutch requires a lighter lever pull compared to cable operated motorcycle clutches.

This system also provides a consistently smooth feeling when the clutch lever is pulled in and released. The hydraulic system automatically compensates for wear and the only maintenance check required is the hydraulic fluid reservoir level.



- **Rocker arms**

With the rocker arms under the camshafts, overall weight is reduced and valve float at high rpm is virtually eliminated.

- **Automatic cam chain adjuster**

The cam chain tensioner automatically compensates for cam chain wear, eliminating periodic adjustment and maintenance.

- **Carburetors with bystarter valve**


The carburetors deliver the proper amount of air/fuel mixture into the cylinder under all operating conditions.

The bystarter valve in each carburetor provides sufficient fuel flow during cranking, making the engine easier to start in cold weather. The bystarter is controlled by the choke lever on the handlebar.

## ONE-WAY CLUTCH SYSTEM

### Purpose:

On rapid downshifting from high RPM, the compression braking forces created by the engine can exceed the rear wheel's traction; the engine becomes a rear wheel brake. This can cause momentary lockup of the rear wheel — until the compression braking force drops below the level necessary to make the rear tire break traction. If multiple downshifts are made, the result will be a much longer loss of traction. The one-way clutch system has been specifically designed to prevent this loss of traction.



### Design:

The major difference between this system and a conventional clutch is a two-piece clutch inner. In addition, the outer portion of the clutch inner, that which controls the majority of the clutch plates and discs, is driven by a special one-way sprag clutch.

- The inner portion of the clutch inner is splined to the transmission's mainshaft as is normal. But it only controls about two-fifths of the clutch plates and discs. This portion of the clutch transmits power and deceleration forces in the usual manner.
- The outer portion of the clutch inner is not splined to the transmission's mainshaft. It controls about three-fifths of the clutch plates and discs. This portion transmits power when the sprag clutch is locked up, such as during normal acceleration, cruising, and deceleration.

### Operation:

When the transmission is downshifted from high RPM, it causes a backloading at the clutch because of the forces generated by the engine's compression braking effect. If these forces approach that which will cause the rear wheel to lock up, the one-way clutch will disengage the outer portion and allow the inner portion to slip. It will do this to a degree that allows the rear wheel to maintain traction while maintaining the highest effect of engine braking. So rather than being a harsh ON or OFF mechanism, the one-way clutch determines the correct amount of slip for each situation, all the while maintaining maximum possible engine braking effect.




• **Operation**



During acceleration, cruising and deceleration, power is transmitted through the clutch in the normal manner:

Clutch outer → friction disc → plate → one-way clutch → mainshaft.

When there is a backloading on the clutch caused by the rear wheel nearing lock-up, the one-way clutch (A) will slip just enough to prevent the wheel from locking: without losing the benefit of maximum engine compression braking.



• **POWER FLOW DIAGRAM**






MEMO



ENGINE DOES NOT START OR IS HARD TO START	23-1
ENGINE LACKS POWER	23-2
POOR PERFORMANCE AT LOW AND IDLE SPEEDS	23-3
POOR PERFORMANCE AT HIGH SPEED	23-3
POOR HANDLING	23-3


## ENGINE DOES NOT START OR IS HARD TO START








## ENGINE LACKS POWER






**POOR PERFORMANCE AT LOW AND IDLE SPEEDS**




**POOR PERFORMANCE AT HIGH SPEED**

NOTE: Ignition to the No. 2 and No. 4 cylinders is cut-off at 11,300–11,800 rpm to prevent engine damage.



**POOR HANDLING** → Check tire and suspensions pressures





MEMO